


Joystick, RH



Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	597921		Joystick, RH				
1	*a 260578	1	. Kit, Handle Cases And Triggers (Black)	3	260581	1	. Kit, Dual Axis Prop. Micro Joystick
		1	.. Handle Halves (Black)			1	.. Prop. Micro Joystick - Standard
		2	.. Adapter Insert (Black)			1	.. Micro Joystick Thumbrest Support
		1	.. Trigger Insert (Black)			1	.. Micro Joystick Panel Nut
		1	.. Single Trigger (Black)	4	260583	4	. Kit, Push Button Switch (100 ma)
		1	.. Lower Trigger (Black)	5	260585	1	. Boot Assembly
		1	.. Double Trigger (Black				
		1	.. Deadman Insert (Black)				
		1	.. Deadman Lever (Black)				
2	260580	1	. Kit, Trigger Switch & Hardware				
		2	.. Push Button Switch (100 ma)				
		2	.. Leaf Spring				
		4	.. Trigger Switch Screw				

*a Kit includes some parts not used in this joystick.