

Auto Lube System, Boom HL

Auto Lube System, Boom HL


Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
			601921				
			Auto Lube System, Boom HL				
3.1	231248	7	. Clamp	3.11	231296	3	. Clamp
3.2	* 592591	1	. Distribution Block, 8 Port	3.12	231251	1	. Clamp
3.3	* 592528	4	. Metering Unit No. 9	3.13	209790	2	. Fitting
3.4	* 592527	2	. Metering Unit No. 8	3.99	601925	1	. Kit, Hose
3.5	* 592554	1	. Plug, Twin Metering	3.99.1	237915	2	.. Hose Assembly
3.6	* 592583	1	. Switch, Pressure	3.99.2	28973	1	.. Hose Assembly
3.7	229551	4	. Fitting	3.99.3	233887	1	.. Hose Assembly
3.8	293797W	2	. Capscrew	3.99.4	227978	1	.. Hose Assembly
3.9	209750	10	. Fitting	3.99.5	601924	2	.. Hose Assembly
3.10	231249	1	. Clamp	3.99.6	596527	1	.. Hose Assembly

* Not Included in 601921. Included in Kit 601918.

BOOM ROUTING	
ROUTE	TO
B1	RH BOOM TO CHASSIS PIVOT
B2	LH BOOM TO CHASSIS PIVOT
B3	RH BOOM TO CARR PIVOT
B4	RH HOIST CYL STEM PIVOT
B5	LH BOOM TO CARR PIVOT
B6	LH HOIST CYL STEM PIVOT



DETAIL 14Z14
BOOM GREASE DISTRIBUTION MANIFOLD



SECTION 14Y14-14Y14
VIEW ROTATED FOR CLARITY

