


Joystick



Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
602115 Joystick							
1	*a 260578	1	. Kit, Handle Cases And Triggers (Black)	2	260580	1	. Kit, Trigger Switch & Hardware
		1	.. Handle Halves (Black)			2	.. Push Button Switch (100 ma)
		2	.. Adapter Insert (Black)			2	.. Leaf Spring
		1	.. Trigger Insert (Black)			4	.. Trigger Switch Screw
		1	.. Single Trigger (Black)	3	260583	6	. Kit, Push Button Switch (100 ma)
		1	.. Lower Trigger (Black)	4	260585	1	. Boot Assembly
		1	.. Double Trigger (Black)	5	260587	1	. Switch Panel; 6 Button
		1	.. Deadman Insert (Black)				
		1	.. Deadman Lever (Black)				

*a Kit includes some parts not used in this joystick.