


Electrical System - Cab

Electrical System - Cab




Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
602162 Electrical System - Cab							
1	* 600332	1	. Assembly, Overhead Console	46	586109	2	. Grommet, Rubber
2	* 597914	1	. Assembly, Dash	47	81905	8	. Grommet
3	* 597899	1	. Assembly, Panel - Front LH	48	242141	3	. Plug, Dome 3/4"
4	* 597898	1	. Assembly, Panel - Front RH	49	598913	6	. Plug, Dome 9/16
6	598937	1	. Power Converter	51	79603	1	. Module, Expansion
7	072-0073	1	. Latch, Lid Stay	52	65290	2	. Machine Screw
10	604474	1	. Gateway W/ Sim	53	WCT0000187	6	. Washer
11	R13803444	2	. Locknut	54	* 602716	1	. Wiring, Cab
12	R13812210	8	. Washer	55	599681	1	. Wire Harness
13	220446W	2	. Capscrew		240519	1	. . Thermistor, 1.3 Ohms
14	596489	2	. Machine Screw		600615	2	. . Relay, Mini Iso
17	18699W	4	. Capscrew	56	593637	1	. Horn, Dual Trumpet
19	R13803445	2	. Locknut	60	Y25G-(1024)12	2	. Capscrew
20	R13812212	24	. Washer	68	R740836	1	. Nut
21	Y25G-(1024)10	20	. Capscrew	70	R10547	1	. Buzzer
23	R13806823	4	. Locknut	71	604475	1	. Antenna
24	223428	10	. Washer	72	604487	1	. Plate, Adapter
25	R13801792	6	. Capscrew	73	15113W	2	. Locknut
26	256319	1	. Receptacle	74	221763W	2	. Washer
27	241295	1	. Receptacle	75	599853	1	. Display, Programmed
28	R10581	1	. Stud, Battery Feeder	76	591879	1	. Bracket, Mounting
29	241826	4	. Receptacle, Wedgelock	77	16338W	2	. Capscrew
30	587704	1	. Rod	79	602794	1	. Bracket, Monitor Mount
31	Y10E-06	6	. Lockwasher	80	296148W	4	. Capscrew
32	221707W	2	. Hex Nut	81	R13809520	2	. Nut
33	237567	2	. Locknut				
34	256320	1	. Light, Dome Red LED				
35	594067	2	. Speaker, Flush Mount				
36	230839	1	. Connector, Cord				
38	234271	6	. Washer				
39	Y17D-10	3	. Locknut				
42	221767W	4	. Washer				
43	221499W	2	. Capscrew				
44	Y17C-1028	3	. Capscrew				
45	601057	1	. Antenna				


* See Separate Coverage




NOTES:

- * INSTALL PLUG UNLESS THE OPTION WILL BE INSTALLED, THEN INSTALL THE GROMMET. RETURN TO STOCK/SCRAP THE COMPONENTS NOT USED
- 1: ALL ROOF MOUNTED COMPONENTS ARE MAGNETIC SO THAT THEY CAN BE REMOVED FROM THE ROOF QUICKLY AND STORED ON THE BACK OF THE CAB.
- 2: WHEN ROUTING CABLES & WIRES TO THE ROOF. ALLOW WIRES TO DROOP SLIGHTLY BELOW THE GROMMET TO PREVENT WATER FROM FOLLOWING THE WIRES INTO THE CAB.







SECTION 2D1-2D1




SECTION 2B1-2B1




SECTION 2F1-2F1




SECTION 2E1-2E1



SECTION 2G2-2G2
VIEW ROTATED



SECTION 2H2-2H2



SECTION 2C1-2C1