


Front Wheel & Tire Assembly



Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	602167		Front Wheel & Tire Assembly				
1	606299	1	. Rim Assembly	1.7	221834	1	. Spud Assembly
1.2	na	0	.. Flange	1.8	222244	1	.. Stem, Valve
1.3	na	0	.. Bead Seat	1.9	221835	1	.. Housing, Core
1.4	na	0	.. Ring, Lock	1.10	na	0	.. Adapter
1.5	na	0	.. Locking Lug	2	602168	1	. Tire
1.6	206062	1	.. O-Ring				