

Seat Assembly Installation




Seat Assembly Installation


Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	602502		Seat Assembly Installation				
1.1	* 601871	1	. Seat Assembly, Highback	1.48	18720W	14	. Capscrew
1.2	598424	1	. Platform	1.56	221499W	4	. Capscrew
1.3	598258	1	. Cover Plate	1.59	596491	20	. Machine Screw
1.4	* 602501	1	. Assembly, Seat Rotate	1.60	596258	2	. Cup Holder
1.5	221767W	20	. Washer	1.91	R13811032	4	. Capscrew
1.7	221771W	6	. Washer	1.92	200454W	6	. Capscrew
1.8	223654	4	. Locknut	1.93	R13812212	16	. Washer
1.10	Y17C-0616	8	. Capscrew	1.94	R13803445	8	. Locknut
1.33	588904	1	. Shim	1.95	599703	1	. Switch, Ignition W/ Keys
1.37	* 246923	1	. Throttle Assembly		260969	1	. Key
1.40	* 598943	1	. Assembly, Steering Column	1.96	546943	1	. Decal, Ignition Switch
1.41	602503	1	. Steering Column	1.98	599454	1	. Steering Cover
1.42	598427	3	. Plate, Column Side	1.99	R13810990	7	. Capscrew
1.47	208264	2	. Grommet	1.100	221763W	7	. Washer

* See Separate Coverage




SECTION 3C3-3C3





SECTION 4D3-4D3



SECTION 4F3-4F3