





Cummins Tier 4 Engine Harness Installation


Cummins Tier 4 Engine Harness Installation

Item	Part No.	Qty	Description	Item	Part No.	Qty	Description
	602699		Cummins T4 Eng Harness Inst				
1	602701	1	. Harness, Cummins T4 Engine	16	234271	2	. Washer
	597377	5	. . Relay, Micro, 24V SPDT	17	R13801840	2	. Capscrew
	597379	2	. . Fuse, Auto Mini, 10Amp	18	231251	3	. Clamp
	597380	1	. . Fuse, Auto Mini, 15Amp	19	595326	A/R	. Mount, Tack
	597382	1	. . Fuse, Auto Mini, 30Amp	20	249329	A/R	. Cable Tie
2	599855	1	. Bracket, Assembly	21	R13808095	8	. Clip, Insulated
3	599797	1	. Boot Connector, 96 Pin	22	221767W	16	. Washer
9	599845	7	. Bracket, Wiring	23	293629W	8	. Capscrew
10	221771W	4	. Washer	24	302401W	8	. Locknut
11	293644W	1	. Capscrew	25	18423W	4	. Washer
12	236805	1	. Capscrew	26	00109451	4	. Screw, Machine
13	R13811432	1	. Washer				
14	293645W	1	. Capscrew				
15	234132	2	. Capscrew				







SECTION 2B1-2B1
SOME PARTS REMOVED FOR CLARITY



SECTION 2C1-2C1
ENGINE REMOVED FOR CLARITY



SECTION 3D1-3D1



SECTION 3E1-3E1
SOME PARTS REMOVED FOR CLARITY

