




Filter Arrangement



Clean/Replace Diesel Particulate Filter (DPF)
Consult with Caterpillar Service Department




588188 Filter, Primary Fuel
Access Under Chassis



587565 Filter, Oil
Access Under Chassis

225556 Filter, Cooling
Access Under Chassis



587568 Filter, Secondary Fuel
Access Under Chassis