

# MASTER CHECK SHEET

**wagner** PARTS BOOK INDEX

DATE 9-2-86

REVISED 8-1-89

PAGE 1 of 6

MODEL L-90

SERIAL NO. 039284

## GENERAL INFORMATION

## SECTION 1

----- Master Check Sheet  
80-35 How to use your Master Check Sheet  
80-7 Parts Ordering Procedure  
----- Quick Reference Filters & Belts L-90/039284  
800081 Structure Nomenclature  
533685 Decal Locations

## POWER UNIT

## SECTION 2

**2-1 Engine**  
W10515 Power Unit  
224005 Engine Specs., CUMMINS NT 855C-335 BC, S/N 11219411  
----- Engine Parts Catalog (3379599)

**2-2 Controls**  
----- Engine Controls - See Section 7-1  
----- Audiovisual Engine Protection System - See Section 6-1

**2-3 Lubrication**  
556263 Lube Oil System - Bypass Filter

**2-4 Fuel**  
541761 Fuel System  
----- Fuel Filter - See Engine Parts Catalog

**2-5 Air Intake & Exhaust**  
545845 Air Intake System  
215155 Air Cleaner  
561607 Exhaust System  
----- Exhaust Blankets - See Exhaust System

**2-6 Cooling**  
558405 Radiator & Shroud  
225076 Radiator  
524881 Deaeration System

**2-7 Miscellaneous**  
526723 Cold Start (Quick Start)

# MASTER CHECK SHEET

**wagner** PARTS BOOK INDEX

DATE 9-2-86  
REVISED 8-1-89

PAGE 2 of 6  
MODEL L-90  
SERIAL NO. 039284

## DRIVETRAIN

## SECTION 3

- 3-1 General**  
548182 Drivetrain Installation
- 3-2 Transmission/Converter**  
----- Converter Installation - See Section 3-1  
219292 Transmission, ALLISON CRT-5633 S/N 3110094487  
----- ALLISON Transmission Parts Catalog (SA 1559)  
80-133 Transmission P/N Cross Reference  
542380 Transmission Circuit (Ref)  
212699 Transmission Filter  
557840 Transmission Control Assembly  
----- Transmission Shift Controls - See Section 7  
----- Transmission Air Cylinder - See Section 4-5  
----- Transmission Air Valve - See Section 4-4
- 3-3 Drivelines**  
----- Driveline Installation - See Section 3-1  
525615 Trans/Intermediate Support Driveline  
525620 Intermediate Support/Axle Driveline  
222662 Intermediate Support Bearing  
525623 Pump Driveline
- 3-4 Axles**  
547355 Drive Axle  
544897 Tailpost
- 3-5 Wheels & Tires**  
540664 Front Wheel (Drive)  
561173 Rear Wheel (Tail)  
----- Front Tires, 37.5 x 33 54PR L-5  
----- Rear Tires, 26.5 x 25 24PR L-3

## AIR & BRAKE SYSTEMS

## SECTION 4

- 4-1 Systems**  
561543 Air System - Failsafe Brake  
542791 Air System - Implement Controls  
542690 Air System - Auxiliary Holddown  
550154 Hydraulic Brake System
- 4-2 Modules**  
----- Control Panel, LH - See Air System - Implement  
----- Control Panel, RH - See Air System - Implement
- 4-3 Supply Components**  
224794 Air Dryer  
217734 Expello Valve

# MASTER CHECK SHEET

**wagner** PARTS BOOK INDEX

DATE 9-2-86  
REVISED 8-1-89

PAGE 3 of 6  
MODEL L-90  
SERIAL NO. 039284

## AIR & BRAKE SYSTEMS

## SECTION 4

### 4-4 Control Components

201358 Regulator Valve  
201352 Holdback Valve  
211315 Relay Valve  
214161 Relay Valve  
216285 Relay Valve  
216615 Relay Valve  
216808 Relay Valve  
214127 Rotary Valve  
215085 Solenoid Valve  
211369 Treadle Valve  
218928 Brake Valve  
219113 Control Valve, RH (Hoist & Tilt)  
215115 Control Valve, LH (HD & KO)  
208707 Control Valve  
207272 Push Button Valve

### 4-5 Actuator Components

223647 Transmission Control Air Cylinder  
220326 Declutch Air Cylinder  
219109 Implement Air Cylinder, Holddown & Kickoff  
219110 Implement Air Cylinder, Hoist & Tilt  
505238 Implement Air Cylinders Auxiliary Holddown  
220267 Brake Actuator Assembly  
222010 Brake Actuator, Service  
217201 Brake Actuator, Parking  
222331 Master Cylinder, Service Brake  
----- Brake Caliper - See Section 3-4  
537433 Parking Brake Installation

### 4-6 Miscellaneous

207906 Air Horn  
509574 Air Hose Kit

## HYDRAULIC SYSTEM

## SECTION 5

### 5-1 Systems/Circuits

560881 Hydraulic System - Steering  
542784 Hydraulic System - Hoist & Tilt (Ref)  
542784-1 Hoist Cylinder Hydraulics (Ref)  
542784-2 Tilt Cylinder Hydraulics (Ref)  
542784-3 Hoist & Tilt Valve Hydraulics (Ref)  
560892 Hydraulic System - HD & KO, LH  
560893 Hydraulic System - HD & KO, RH  
561689 Hydraulic System - Auxiliary Holddown

(Continued)

# MASTER CHECK SHEET

**wagner** PARTS BOOK INDEX

DATE 9-2-86  
REVISED 8-1-89

PAGE 4 of 6  
MODEL L-90  
SERIAL NO. 039284

## HYDRAULIC SYSTEM (Continued)

SECTION 5

**5-2 Pumps**  
218965 Tandem Pump - Holddown & Kickoff, R&LH  
217234 Single Pump - Steering

**5-3 Valves**  
542789 Valve Module  
220707 Steering Valve & Column  
213907 Hoist & Tilt Valve  
530746 Holddown/Kickoff Valve, LH  
216881 Holddown/Kickoff Valve, RH  
215130 Auxiliary Holddown Valve  
211759 Relief Valve  
210945 Relief Valve

**5-4 Cylinders**  
800089 Hydraulic Cylinder Locations (Ref)  
505619 Steering Cylinder  
557499 Hoist Cylinder  
543045 Tilt Cylinder  
526164 Holddown Cylinder  
526154 Kickoff Cylinder  
534020 Auxiliary Holddown Cylinder

**5-5 Filters**  
224365 High Pressure Filter Strainer  
210092 Return Filter  
509413 Return Strainer (In-Tank)  
----- Transmission Filter - See Section 3-2

**5-6 Miscellaneous**  
552658 Hydraulic Tank Heater  
537587 Hydraulic Tube Coupling  
80-60 O-Ring Service  
224408 Pressure Differential Switch

## ELECTRICAL SYSTEM

SECTION 6

**6-1 Systems/Circuits**  
550555 Audiovisual Engine Protection System  
539396 Reverse Alarm Circuit  
555269 Neutral Start Circuit

(Continued)

# MASTER CHECK SHEET

**wagner** PARTS BOOK INDEX

DATE 9-2-86  
REVISED 8-1-89

PAGE 5 of 6  
MODEL L-90  
SERIAL NO. 039284

## ELECTRICAL SYSTEM (Continued)

SECTION 6

6-2	Components
560367	Cowl Wiring
561441	Chassis Wiring
561442	Battery Cables
561315	Alternator Installation
227425	Alternator
560054	Instrument Panel
560246	Instrument Panel Wiring
560191	Cowl Terminal Board
560085	Junction Box
-----	Battery Box - See Section 8
800004	Lighting Components
550681	Halogen Light Bar
800008	Warning Light Installation

## CAB & COWL

SECTION 7

559642	Cab Assembly
560053	Cowl Assembly
800006	Cowl Installation Hardware
559644	Door Assembly, LH
559643	Door Assembly, RH
559647	Door Latch, LH
559646	Door Latch, RH
554939	Cab & Cowl Insulation
557844	Engine & Transmission Controls
800005	Steering Wheel Components
-----	Steering Column - See Section 5-3
525444	Air Conditioner Installation
80-256	Air Conditioner Assembly
524302	Heater Installation
213018	Heater Assembly
214971	Cab Pressurizer
800007	Defroster
557651	Windshield Wipers, Front & Rear
553905	Seat Suspension
220900	Seat Assembly

# MASTER CHECK SHEET

6 of 6

**wagner** PARTS BOOK INDEX

PAGE \_\_\_\_\_

L-90

MODEL \_\_\_\_\_

039284

DATE 9-2-86

SERIAL NO. \_\_\_\_\_

REVISED 8-1-89

## FRAME & ATTACHMENTS

SECTION 8

558676	Boom Assembly
561526	Carriage Assembly
561358	Auxiliary Holddown Installation
-----	Tailpost - See Section 3-4
800088	Pin & Bushing Composite
80-220	Miscellaneous Chassis Parts
551550	Battery Box

## ACCESSORIES & OPTIONS

SECTION 9

561850	Fire Suppression System
--------	-------------------------

PARTS