

# MASTER CHECK SHEET

**wagner** SERVICE BOOK INDEX

DATE 12-19-86  
REVISED 8-1-89

PAGE 1 of 4  
MODEL L-90  
SERIAL NO. 039285

## GENERAL INFORMATION

### SECTION 1

----- Master Check Sheet  
80-35 How to use your Master Check Sheet  
80-103 Start & Stop Procedures  
0081 Loctite Application  
0130 Capscrew Grades & Torque Values  
80-245 Manufacturer's Warranty

## POWER UNIT

### SECTION 2

**2-1 Engine**  
----- Cummins Engine Warranty  
----- CUMMINS Operation & Maintenance Manual (3379052)

**2-2 Controls**  
----- Audiovisual Engine Protection System-See Section 6-1

**2-3 Lubrication**  
556263 Lube Oil System

**2-4 Fuel System**  
541761 Fuel System

**2-5 Air Intake & Exhaust**  
80-45 Air Filter Service  
0024 Service Gauge Operation

**2-6 Cooling**  
0124 Radiator Fill  
80-287 Radiator Service  
524881 Deaeration System

**2-7 Miscellaneous**  
80-196 Cold Start Operation

# MASTER CHECK SHEET

**wagner** SERVICE BOOK INDEX

PAGE 2 of 4  
MODEL L-90  
SERIAL NO. 039285

DATE 12-19-86  
REVISED 8-1-89

## DRIVETRAIN

## SECTION 3

- 3-1 General**  
564996 Drivetrain Installation (Ref)
- 3-2 Transmission/Converter**  
----- CLARK Transmission Service Manual (SM-54)  
----- CLARK Converter Service Manual (SM-8000)  
561342 Transmission Circuit  
0017 Transmission Breather Maintenance  
----- Transmission Filter Service See Trans. Manual
- 3-3 Drivelines**  
0054 Driveline Installation & Lube  
0182 Driveline Torque Settings
- 3-4 Axles**  
80-243 Axle Installation  
----- CLARK Axle Service, 85,000 Series (DA-850)  
80-119 Tailpost Installation
- 3-5 Wheels & Tires**  
0179 Wheel & Tire Maintenance  
0183 Rim & Tire Safety  
80-67 Tire Pressures

## AIR & BRAKE SYSTEM

## SECTION 4

- 4-1 Systems**  
561543 Air System - Failsafe  
542791 Air System - Implement  
550154 Hydraulic Brake System
- 4-2 Modules**
- 4-3 Supply Components**  
80-242 Air Dryer Service  
80-194 Expello Valve Service
- 4-4 Control Components**
- 4-5 Actuator Components**  
80-174 Maxi Brake Operation  
80-227 Disc Brake Service  
80-258 Air Chamber Service  
80-263 Master Cylinder Service

(Continued)

# MASTER CHECK SHEET

**wagner** SERVICE BOOK INDEX

DATE 12-19-86

REVISED 8-1-89

PAGE 3 of 4

MODEL L-90

SERIAL NO. 039285

## AIR & BRAKE SYSTEM (Continued)

SECTION 4

- 4-6**            **Miscellaneous**
- 80-305        Basic Declutch System Diagram
- 0154           Declutch System Troubleshooting

## HYDRAULIC SYSTEM

SECTION 5

- 5-1**            **Systems/Circuits**
- 563247        ANSI Hydraulic Schematic (Ref)
- Lumberjack Power Beyond System - Color Coded Schematic
- 561562        Hydraulic System - Steering
- 542784        Hydraulic System - Hoist & Tilt
- 561532/33     Hydraulic System - Holddown & Kickoff
- 0040           Flushing Systems
- 80-187        Troubleshooting Hydraulic Systems
- 130-8         Systems Pressures
- 80-336        Hydraulic Pressure Check Points
  
- 5-2**            **Pumps**
- HD/KO & Steering Pump Service (HS-17)
- 0079           Hydraulic Pump Failures
  
- 5-3**            **Valves**
- 80-251        Steering Control Unit Service
- 80-252        Steering Valve Service
- 80-280        Hoist & Tilt Control Valve Service
- 80-284        Holddown & Kickoff Valve Service
  
- 5-4**            **Cylinders**
- 80-44         Cylinder Service
  
- 5-5**            **Filters**
- 80-244        High Pressure Filter Service
- 0137           Return Filter Service
- Transmission Filter - See Section 3-2
  
- 5-6**            **Miscellaneous**

## ELECTRICAL SYSTEM

SECTION 6

- 6-1**            **Systems/Circuits**
- 561509        Electrical System Schematic (Ref)
- 550555        Audiovisual Engine Protection System
- 539396        Reverse Alarm Circuit
- 555269        Neutral Start Circuit

(Continued)

# MASTER CHECK SHEET

**wagner** SERVICE BOOK INDEX

PAGE 4 of 4

MODEL L-90

DATE 12-19-86

SERIAL NO. 039285

REVISED 8-1-89

## ELECTRICAL SYSTEM

SECTION 6

6-2	Components
80-92	Battery Maintenance
0161	Alternator Servicing Precautions
80-238	Alternator Service
80-140	Volt Guard Operation
560054	Instrument Panel
560246	Instrument Panel Wiring
80-180	Tachometer Service
80-333	Audiovisual Engine Protection System Maintenance

## CAB & COWL

SECTION 7

0197	Cab Tilting Procedure
80-259	Heater/Air Conditioner Operation & Service

## FRAME & ATTACHMENTS

SECTION 8

-----	Tailpost Installation - See Section 3-4
-------	---

## ACCESSORIES

SECTION 9

80-125	Fire Suppression System Service
--------	---------------------------------

## MAINTENANCE & LUBRICATION

SECTION 10

80-229	Maintenance & Lubrication - General
0025	Initial Lubrication
80-24	Maintenance Check, Daily
80-25	Maintenance Check, 50, 250 & 500 Hrs.
80-26	Maintenance Check, 1000 & 2000 Hrs.
-----	L-90 Maintenance & Lubrication (Ref)
80-212	Systems Capacities