

MASTER CHECK SHEET

wagner PARTS BOOK INDEX

DATE 7-30-87
REVISED 8-2-89

PAGE 1 of 6
MODEL L-90
SERIAL NO. 039287

GENERAL INFORMATION

SECTION 1

----- Master Check Sheet
80-35 How to use your Master Check Sheet
80-7 Parts Ordering Procedure
----- Quick Reference Filters & Belts L-90/039287
800081 Structure Nomenclature
533685 Decal Locations

POWER UNIT

SECTION 2

2-1 **Engine**
W10433 Power Unit (Ref)
225973 Engine Specs., CUMMINS NTA-855-C335 BC3 S/N 11405427
----- Engine Parts Catalog (3822000)

2-2 **Controls**
----- Engine Controls - See Section 7-1
----- Audiovisual Engine Protection System - See Section 6-1

2-3 **Lubrication**
556263 Lube Oil System - Bypass Filter

2-4 **Fuel**
541761 Fuel System
----- Fuel Filter - See Engine Parts Catalog

2-5 **Air Intake & Exhaust**
562376 Air Intake System
217443 Air Cleaner
561607 Exhaust System
----- Exhaust Blankets - See Exhaust System

2-6 **Cooling**
558405 Radiator & Shroud Asm
225076 Radiator
524881 Deaeration system

2-7 **Miscellaneous**
526723 Cold Start (Quick Start)

MASTER CHECK SHEET

wagner PARTS BOOK INDEX

PAGE 2 of 6

MODEL L-90

DATE 7-30-87

SERIAL NO. 039287

REVISED 8-2-89

DRIVETRAIN

SECTION 3

- 3-1 General**
548182 Drivetrain Installation
- 3-2 Transmission/Converter**
219292 ALLISON Trans., CRT-5633-TC-570, S/N 3110095437
80-133 Allison P/N Cross Reference
----- Transmission Parts Catalog (SA 1559)
542380 Transmission Circuit
212699 Transmission Filter
----- Transmission Shift Controls - See Section 7
557840 Transmission Control Asm
----- Transmission Air Cylinder - See Section 4-5
----- Transmission Control Air Valve - See Section 4-4
- 3-3 Drivelines**
----- Driveline Installation - See Section 3-1
525615 Transmission/Support Driveline
525620 Support/Axle Driveline
222662 Driveline Support Bearing
525623 Pump Driveline
- 3-4 Axles**
547355 Drive Axle, S/N GUSA 651447
544897 Tailpost
- 3-5 Wheels & Tires**
547331 Front Wheel (Drive)
511427 Rear Wheel (Steer)
----- Front Tires, 33.5 x 33 (L-3)
----- Rear Tires, 23.5 x 25 (20 PLY)

AIR & BRAKE SYSTEMS

SECTION 4

- 4-1 Systems**
561534 Air System - Failsafe Brake
542791 Air System - Implement Controls
550154 Hydraulic Brake System
- 4-2 Modules**
----- Control Panel, LH - See Air System - Implement
----- Control Panel, RH - See Air System - Implement
- 4-3 Supply Components**
224794 Air Dryer
217734 Expello Valve

MASTER CHECK SHEET

wagner PARTS BOOK INDEX

PAGE 3 of 6

MODEL L-90

DATE 7-30-87

SERIAL NO. 039287

REVISED 8-2-89

AIR & BRAKE SYSTEMS

SECTION 4

4-4 Control Components

201358 Regulator Valve
216615 Relay Valve
201352 Holdback Valve
211315 Relay Valve
214161 Relay Valve
216285 Relay Valve
216808 Relay Valve
214127 Rotary Valve
215085 Solenoid Valve
211369 Treadle Valve
218928 Brake Valve
219113 Quad Valve
215115 Control Valve Asm
223644 Trans Control Valve
207272 Push Button Valve
208707 Push Button Valve

4-5 Actuator Components

223647 Fwd & Rev Air Cylinder
220326 Declutch Air Cylinder
219109 Implement Air Cylinder, Holddown & Kickoff
219110 Implement Air Cylinder, Hoist & Tilt
220267 Brake Actuator Assembly
222010 Brake Air Chamber, Service
217201 Brake Air Chamber, Parking
222331 Master Cylinder, Service Brake
----- Brake Caliper - See Section 3-4
537433 Parking Brake Installation

4-6 Miscellaneous

207906 Air Horn
509574 Air Hose Kit

HYDRAULIC SYSTEM

SECTION 5

5-1 Systems/Circuits

563143 Hydraulic System - Steering
542784 Hydraulic System - Hoist & Tilt
542784-1 Hoist Cylinder Plumbing
542784-2 Tilt Cylinder Plumbing
542784-3 Valve to Tank Plumbing
563273 Chassis Hydraulics - Holddown & Kickoff

MASTER CHECK SHEET

wagner PARTS BOOK INDEX

DATE 7-30-87
REVISED 8-2-89

PAGE 4 of 6
MODEL L-90
SERIAL NO. 039287

HYDRAULIC SYSTEM (Continued)

SECTION 5

- 5-1 Systems/Circuits (Continued)**
563278 Boom Plumbing
563297 Carriage Hydraulics - Holddown & Kickoff
- 5-2 Pumps**
217234 Single Pump - Steering
218965 Tandem Pump - Holddown & Kickoff, L & RH
- 5-3 Valves**
561561 Valve Module
224731 Steering Control Unit
226211 Steering Valve
225151 Hoist & Tilt Valve
223725 Holddown/Kickoff Valve, LH
223726 Holddown/Kickoff Valve, RH
- 5-4 Cylinders**
800089 Hydraulic Cylinder Locations
505619 Steering Cylinder
557499 Hoist Cylinder
538258 Tilt Cylinder
526164 Holddown Cylinder
526154 Kickoff Cylinder
- 5-5 Filters**
228201 High Pressure Filter (100 GPM)
210092 Return Filter
509413 Return Strainer (In-Tank)
----- Transmission Filter - See Section 3-2
- 5-6 Miscellaneous**
537587 Hydraulic Tube Coupling
80-60 O-Ring Service
552658 Hydraulic Tank Heater

ELECTRICAL SYSTEM

SECTION 6

- 6-1 Systems/Circuits**
550555 Audio Visual Engine Protection System
539396 Reverse Alarm Circuit
555269 Neutral Start Circuit

(Continued)

MASTER CHECK SHEET

wagner PARTS BOOK INDEX

PAGE 5 of 6

MODEL L-90

DATE 7-30-87

SERIAL NO. 039287

REVISED 8-2-89

ELECTRICAL SYSTEM (Continued)

SECTION 6

6-2	Components
560367	Cowl Wiring
561441	Chassis Wiring
561442	Battery Cable Routing
224207	Alternator
560054	Instrument Panel
560246	Instrument Panel Wiring
560191	Cowl Terminal Board
560085	Junction Box
-----	Battery Box - See Section 8
800004	Lighting Components

CAB & COWL

SECTION 7

559642	Cab Assembly
560053	Cowl Assembly
800006	Cowl Installation Hardware
559644	Door Assembly, LH
559643	Door Assembly, RH
559647	Door Latch, LH
559646	Door Latch, RH
554939	Cab & Cowl Insulation
557844	Engine & Transmission Controls
-----	Transmission Control Asm - See Section 3-2
800005	Steering Wheel Components
550598	Heater/Air Conditioner Installation
218869	Heater/Air Conditioner Asm
214971	Cab Pressurizer
800007	Defroster
557651	Windshield Wipers, Front & Rear
553905	Seat Suspension
220900	Seat Assembly

MASTER CHECK SHEET

wagner PARTS BOOK INDEX

PAGE 6 of 6

MODEL L-90

DATE 7-30-87

SERIAL NO. 039287

REVISED 8-2-89

FRAME & ATTACHMENTS

SECTION 8

- 558676 Boom Assembly
- 561058 Carriage Assembly
- Tailpost - See Section 3-4
- 800098 Pin & Bushing Composite
- 800097 Miscellaneous Chassis Parts
- 551550 Battery Box

ACCESSORIES & OPTIONS

SECTION 9

- 561850 Fire Suppression System

PARTS