

MASTER CHECK SHEET

wagner PARTS BOOK INDEX

DATE 12-9-87
REVISED 8-7-88

PAGE 1 of 5
MODEL L-90
SERIAL NO. 039288

*Back Order

GENERAL INFORMATION

SECTION 1

----- Master Check Sheet
80-35 How to use your Master Check Sheet
80-7 Parts Ordering Procedure
----- Quick Reference, Filters & Belts, L-90/039288
800081 Structure Nomenclature
533685 Decal Locations

POWER UNIT

SECTION 2

2-1 Engine
564045 Power Unit
228664 Engine Specifications, CAT 3406B-DI, S/N 7FB89419
----- Engine Parts Catalog (SEBP 1434)

2-2 Controls
----- Engine Controls - See Section 7-1
----- Audiovisual Engine Protection Sys - See Section 6-1

2-3 Lubrication
564078 Engine Oil Filter Plumbing - Bypass Filter
563698 Oil Filler

2-4 Fuel
558024 Fuel System
----- Fuel Filter - See Engine Parts Catalog

2-5 Air Intake & Exhaust
563948 Air Intake System
224214 Air Cleaner
563942 Exhaust System

2-6 Cooling
563629 Radiator Installation
562197 Radiator

2-7 Miscellaneous
524304 Cold Start (Quick Start)

MASTER CHECK SHEET

wagner PARTS BOOK INDEX

DATE 12-9-87
REVISED 8-7-89

PAGE 2 of 5
MODEL L-90
SERIAL NO. 039288

DRIVETRAIN

SECTION 3

- 3-1 General**
* Drivetrain Installation
- 3-2 Transmission/Converter**

Converter Installation - See Section 2-1
222142 Transmission, S/N GUSA 7702
~~233076~~ 222141 Converter, S/N GUSA 8142 (~~Model L-8612-62~~)
OV 558343 Transmission Circuit
219271 Transmission Filter

Transmission Shift Controls - See Section 7

Transmission Air Cylinder - See Section 4-5
- 3-3 Drivelines**

Driveline Installation - See Section 3-1
557885 Driveline Assembly, Conv/Trans
528756 Driveline Assembly, Trans/Axle
- 3-4 Axles**
547355 Drive Axle, S/N GUSA 651859
544897 Tailpost
- 3-5 Wheels & Tires**
548241 Front Wheel (Drive)
511427 Rear Wheel (Steer)

Front Tires, 37.5 x 33 54 PR

Rear Tires, 23.5 x 25 20 PLY

AIR & BRAKE SYSTEMS

SECTION 4

- 4-1 Systems**
558025 Air System - Failsafe Brake
542791 Air System - Implement Controls
550154 Hydraulic Brake System
- 4-2 Modules**

Control Panel, LH - See Air System - Implement

Control Panel, RH - See Air System - Implement
- 4-3 Supply Components**
218832 Air Dryer
217734 Expello Valve

MASTER CHECK SHEET

wagner PARTS BOOK INDEX

DATE 12-9-87

REVISED 8-7-89

PAGE 3 of 5

MODEL L-90

SERIAL NO. 039288

AIR & BRAKE SYSTEMS

SECTION 4

4-4 Control Components

201358 Regulator Valve
216615 Relay Valve
201352 Holdback Valve
211315 Relay Valve
214161 Relay Valve
216285 Relay Valve
214127 Rotary Valve
215085 Solenoid Valve
211369 Treadle Valve
218928 Brake Valve
219113 Quad Valve
215115 Control Valve Asm
215204 Control Valve
207272 Push Button Valve
208707 Push Button Valve

4-5 Actuator Components

536470 Transmission Control Air Cylinder
545336 Declutch Air Cylinder
219109 Implement Air Cylinder, Holddown & Kickoff
219110 Implement Air Cylinder, Hoist & Tilt
220267 Brake Actuator Assembly
222010 Brake Air Chamber, Service
217201 Brake Air Chamber, Parking
222331 Master Cylinder, Service Brake
----- Brake Caliper - See Section 3-4
540403 Parking Brake Installation

4-6 Miscellaneous

207906 Air Horn
509574 Air Hose Kit

HYDRAULIC SYSTEM

SECTION 5

5-1 Systems/Circuits

563929 Hydraulic System - Steering
542784 Hydraulic System - Hoist & Tilt
542784-1 Hoist Cylinder Plumbing
542784-2 Tilt Cylinder Plumbing
542784-3 Valve to Tank Plumbing

563922 Chassis Hydraulics
563278 Boom Plumbing
563949 Carriage Hydraulics

(Continued)

MASTER CHECK SHEET

wagner PARTS BOOK INDEX

DATE 12-9-87
REVISED 8-7-89

PAGE 4 of 5
MODEL L-90
SERIAL NO. 039288

HYDRAULIC SYSTEM (Continued)

SECTION 5

- 5-2 Pumps**
225126 Holddown/Kickoff, RH/Steering
225127 Holddown/Kickoff, LH
- 5-3 Valves**
563936 Valve Module
216881 Holddown/Kickoff Valve, LH
530746 Holddown/Kickoff Valve, RH
220707 Steering Valve
225151 Hoist & Tilt Valve
210945 Relief Valve
- 5-4 Cylinders**
800089 Hydraulic Cylinder Locations
505619 Steering Cylinder
557499 Hoist Cylinder
538258 Tilt Cylinder
526164 Holddown Cylinder
526154 Kickoff Cylinder
- 5-5 Filters**
228201 High Pressure Filter (100 GPM)
210092 Return Filter, Hoist & Tilt
509413 Return Strainer (In-Tank)
----- Transmission Filter - See Section 3-2
- 5-6 Miscellaneous**
537587 Hydraulic Tube Coupling
80-60 O-Ring Service

ELECTRICAL SYSTEM

SECTION 6

- 6-1 Systems/Circuits**
557939 Electrical System
558094 Audiovisual Engine Protection System
542689 Reverse Alarm Circuit
555269 Neutral Start Circuit
- 6-2 Components**
560367 Cowl Wiring
561541 Chassis Wiring (Ref)
225061 Alternator
563052 Instrument Panel
560246 Instrument Panel Wiring
560191 Cowl Terminal Board

(Continued)

MASTER CHECK SHEET

5 of 5

wagner PARTS BOOK INDEX

PAGE _____

L-90

MODEL _____

039288

SERIAL NO. _____

DATE 12-9-87REVISED 8-7-89

ELECTRICAL SYSTEM (Continued)**SECTION 6**

560085 Junction Box
----- Battery Box - See Section 8
800004 Lighting Components
800008 Cab Warning Light

CAB & COWL**SECTION 7**

559642 Cab Assembly
562569 Cowl Assembly
800006 Cowl Installation Hardware
559644 Door Assembly, LH
559643 Door Assembly, RH
559647 Door Latch, LH
559646 Door Latch, RH
554939 Cab & Cowl Insulation

563597 Engine & Transmission Controls
800005 Steering Wheel Components

558556 Air Cond/Heater Installation
218869 Air Cond/Heater Assembly
550803 Air Cond Condenser Installation
214971 Cab Pressurizer
800007 Defroster
557651 Windshield Wipers, Front & Rear
553905 Seat Suspension
220900 Seat Assembly

FRAME & ATTACHMENTS**SECTION 8**

558676 Boom Assembly
563742 Carriage Assembly
----- Tailpost - See Section 3-4
800088 Pin & Bushing Composite
800097 Miscellaneous Chassis Parts
551550 Battery Box

ACCESSORIES**SECTION 9**

558744 Fire Suppression System