

MASTER CHECK SHEET

wagner SERVICE BOOK INDEX

PAGE 1 of 4
MODEL L-90
SERIAL NO. 039288

DATE 12-9-87

REVISED 8-7-89

*Back Order

GENERAL INFORMATION

SECTION 1

----- Master Check Sheet
80-35 How to use your Master Check Sheet
80-103 Start & Stop Procedures
0081 Loctite Application
0130 Capscrew Grades & Torque Values
80-245 Manufacturer's Warranty

POWER UNIT

SECTION 2

2-1 **Engine**
----- CAT 3406B Operation & Maintenance Manual (SEBU 5791)

2-2 **Controls**
----- Audiovisual Engine Protection Sys - See Section 6

2-3 **Lubrication**
----- Lube Oil System - See Engine Manual

2-4 **Fuel System**
558024 Fuel System

2-5 **Air Intake & Exhaust**
80-45 Air Filter Service
0024 Service Gauge Operation

2-6 **Cooling**
0124 Radiator Fill
80-287 Radiator Service
524881 Deaeration System

2-7 **Miscellaneous**
80-196 Cold Start Operation & Service

DRIVETRAIN

SECTION 3

* 3-1 **General**
Drivetrain Installation

(Continued)

MASTER CHECK SHEET

wagner SERVICE BOOK INDEX

DATE 12-9-87
REVISED 8-7-89

PAGE 2 of 4
MODEL L-90
SERIAL NO. 039288

DRIVETRAIN (Continued)

SECTION 3

- 3-2 Transmission/Converter**
----- CLARK Transmission Service Manual (SM-84)
----- CLARK Converter Service Manual (SM-8000)
558343 Transmission Circuit
0017 Transmission Breather Maintenance
----- Transmission Filter Service See Trans. Manual
- 3-3 Drivelines**
0054 Driveline Installation & Lube
0182 Driveline Torque Settings
- 3-4 Axles**
80-243 Axle Installation
----- CLARK Axle Service, 85,000 Series (DA-850)
80-119 Tailpost Installation
- 3-5 Wheels & Tires**
0179 Wheel & Tire Maintenance
0183 Rim & Tire Safety
80-67 Tire Pressures

AIR & BRAKE SYSTEM

SECTION 4

- 4-1 Systems**
558025 Air System - Failsafe Brake
542791 Hydraulic - Implement Controls
550154 Hydraulic Brake System
- 4-2 Modules**
- 4-3 Supply Components**
80-265 Air Dryer Service
80-194 Expello Valve Service
- 4-4 Control Components**
- 4-5 Actuator Components**
80-174 Maxi Brake Operation
80-227 Disc Brake Service
80-258 Air Chamber Service
80-263 Master Cylinder Service
- 4-6 Miscellaneous**
80-305 Basic Declutch System Diagram
0154 Declutch System Troubleshooting

MASTER CHECK SHEET

wagner SERVICE BOOK INDEX

DATE 12-9-87

REVISED 8-7-89

3 of 4

PAGE _____

L-90

MODEL _____

SERIAL NO. 039288

HYDRAULIC SYSTEM

SECTION 5

- 5-1 Systems/Circuits**
563247 ANSI Hydraulic Schematic
----- Lumberjack Power Beyond System - Color Coded Schematic
563929 Hydraulic System - Steering
542784 Hydraulic System - Hoist & Tilt
563922 Chassis Plumbing
0040 Flushing Systems
80-187 Troubleshooting Hydraulic Systems
130-8 Systems Pressures
80-336 Hydraulic Pressure Check Points
- 5-2 Pumps**
----- HD/KO & Steering Pump Service, (HS-17)
80-197 Commercial Pump Rotation
0079 Hydraulic Pump Failures
- 5-3 Valves**
----- Steering Control Valve Service (HGB 106)
80-280 Hoist & Tilt Control Valve Service
----- Holddown & Kickoff Valve Service (HU 1881-1 & HU 1811)
- 5-4 Cylinders**
80-44 Cylinder Service
- 5-5 Filters**
80-244 High Pressure Filter Service
0137 Return Filter Service
----- Transmission Filter - See Section 3-2
- 5-6 Miscellaneous**

ELECTRICAL SYSTEM

SECTION 6

- 6-1 Systems/Circuits**
557939 Electrical System Schematic
558094 Audiovisual Engine Protection System
542689 Reverse Alarm Circuit
555269 Neutral Start Circuit

(Continued)

MASTER CHECK SHEET

wagner SERVICE BOOK INDEX

DATE 12-9-87

REVISED 8-7-89

PAGE 4 of 4
MODEL L-90
SERIAL NO. 039288

ELECTRICAL SYSTEM (Continued)

SECTION 6

6-2	Components
80-92	Battery Maintenance
0161	Alternator Servicing Precautions
-----	Alternator Service (1G-280)
80-140	Volt Guard Operation
563052	Instrument Panel
560246	Instrument Panel Wiring
80-180	Tachometer Service
80-333	Audiovisual Engine Protection System Maintenance

CAB & COWL

SECTION 7

0197	Cab Tilting Procedure
80-259	Heater/Air Conditioner Operation & Service

FRAME & ATTACHMENTS

SECTION 8

-----	Tailpost Installation - See Section 3-4
-------	---

ACCESSORIES

SECTION 9

80-125	Fire Suppression System Service
--------	---------------------------------

MAINTENANCE & LUBRICATION

SECTION 10

80-229	Maintenance & Lubrication - General
0025	Initial Lubrication
80-24	Maintenance Check, Daily
80-25	Maintenance Check, 50, 250 & 500 Hrs.
80-26	Maintenance Check, 1000 & 2000 Hrs.
-----	L-90 Maintenance & Lubrication
80-212	Systems Capacities