

MASTER CHECK SHEET

Wagner PARTS BOOK INDEX

DATE 10-12-89

REVISED _____

*Back Order

PAGE 1 of 6

MODEL L-90

SERIAL NO. 039297

GENERAL INFORMATION

SECTION 1

----- Master Check Sheet
80-35 How to use your Master Check Sheet
80-7 Parts Ordering Procedure
----- Quick Reference Filters & Belts L-90/039297
800081 Structure Nomenclature
533685 Decal Locations

POWER UNIT

SECTION 2

2-1 **Engine**
564885 Power Unit
226062 Engine Specs., CUMMINS NTA 855-C335 BC3, S/N 11550151
----- Engine Parts Catalog (3822000)

2-2 **Controls**
----- Engine Controls - See Section 7-2
----- Audiovisual Engine Protection System - See Section 6-1

2-3 **Lubrication**
556263 Lube Oil System - Bypass Filter

2-4 **Fuel**
541761 Fuel System
----- Fuel Filter - See Engine Parts Catalog

2-5 **Air Intake & Exhaust**
562376 Air Intake System
217443 Air Cleaner
561607 Exhaust System

2-6 **Cooling**
----- Radiator & Shroud Installation - See Section 2-1
558405 Radiator & Shroud Asm
230479 Radiator

2-7 **Miscellaneous**
526723 Cold Start (Quick Start)

MASTER CHECK SHEET

wagner PARTS BOOK INDEX

DATE 10-12-89
REVISED _____

PAGE 2 of 6
MODEL L-90
SERIAL NO. 039297

DRIVETRAIN

SECTION 3

3-1 General
564996 Drivetrain Installation

3-2 Transmission/Converter

233075 ~~226974~~ Converter Installation - See Section 2-1
W10659 Converter, ← S/N JUSA 35227 (Model - C 86(2-66))
226930 Transmission Installation
564943 Transmission, S/N JUSA 35176
219271 Transmission Circuit

Transmission Shift Controls - See Section 7-2

Transmission Air Cylinder - See Section 4-5

3-3 Drivelines

530480 Driveline Installation - See Section 3-1
528756 Driveline Assembly, Converter to Transmission
Driveline Assembly, Transmission to Axle

3-4 Axles
547355 Drive Axle, S/N
544897 Tailpost (Rear Axle)

3-5 Wheels & Tires
547331 Front Wheel (Drive)
511427 Rear Wheel (Steer)

Front Tires, 33.5 x 33 44PR L-3 LDNDLCM

Rear Tires, 23.5 x 25 20PR L-3

AIR & BRAKE SYSTEMS

SECTION 4

4-1 Systems
W10793 ~~565165~~ Air System - Failsafe Brake
562690 Air System - Implement Controls (Seat Mounted)
550154 Hydraulic Brake System

4-2 Modules
562692 Control Panel, LH

Control Panel, RH - See Air System - Implement
558554 Air Valve Module

(Continued)

MASTER CHECK SHEET

wagner PARTS BOOK INDEX

DATE 10-12-89

REVISED _____

PAGE 3 of 6

MODEL L-90

SERIAL NO. 039297

AIR & BRAKE SYSTEMS (Continued)

SECTION 4

4-3 Supply Components
226349 Air Dryer
217734 Expello Valve

4-4 Control Components
201358 Regulator Valve
216615 Relay Valve
201352 Holdback Valve
211315 Relay Valve
214161 Relay Valve
216285 Relay Valve
216808 Relay Valve
214127 Rotary Valve
215085 Solenoid Valve
211369 Treadle Valve
218928 Brake Valve
227984 Remote Control Valve
207272 Push Button Valve
208707 Push Button Valve
562230 Control Valve Asm. HD/KO

4-5 Actuator Components
536683 Transmission Control Air Cylinder
545336 Declutch Air Cylinder
219109 Implement Air Cylinder, Holddown & Kickoff
219110 Implement Air Cylinder, Hoist & Tilt
220267 Brake Actuator Assembly
222010 Brake Air Chamber, Service
217201 Brake Air Chamber, Parking
222331 Master Cylinder, Service Brake
----- Brake Caliper - See Section 3-4
561614 Parking Brake Installation

4-6 Miscellaneous
207906 Air Horn
509574 Air Hose Kit

MASTER CHECK SHEET

wagner PARTS BOOK INDEX

DATE 10-12-89
REVISED _____

PAGE 4 of 6
MODEL L-90
SERIAL NO. 039297

HYDRAULIC SYSTEM

SECTION 5

5-1

#566680
#566611
#567865 564627
563278
563297
#567085

Systems/Circuits

Hydraulic System - Steering
Hydraulic System - Hoist & Tilt
~~Hydraulic System - Holddown & Kickoff~~ CHASSIS HYDRAULICS
Boom Plumbing
Carriage Hydraulics
HYDRAULIC SYSTEM - COOLER FAN

5-2

229005
226540

Pumps

Steering/Hydraulic Fan (Piggyback)
Holddown/Kickoff, R&LH (Tandem)

5-3

#567089 #565914
224731
*231179
225151
230669
566303 565604
218007
*229539

Valves

Valve Module
Steering Control Unit (Pilot)
Steering Valve
Hoist & Tilt Valve
Holddown/Kickoff Valve, LH
Holddown/Kickoff Valve, RH
RELIEF VALVE
SOLENOID VALVE

5-4

800089
505619
557499
538258
526164
526154

Cylinders

Hydraulic Cylinder Locations
Steering Cylinder
Hoist Cylinder
Tilt Cylinder
Holddown Cylinder
Kickoff Cylinder

5-5

228201
210092
509413

Filters

High Pressure Filter (100 GPM)
Return Filter, Hoist & Tilt
Return Strainer (In-Tank)
Transmission Filter - See Section 3-2

5-6

#228120

537587
80-60

Miscellaneous

Oil Cooler Installation Assembly
Hydraulic Tank Heater
Hydraulic Tube Coupling
O-Ring Service

MASTER CHECK SHEET

wagner PARTS BOOK INDEX

DATE 10-12-89
REVISED _____

PAGE 5 of 6
MODEL L-90
SERIAL NO. 039297

ELECTRICAL SYSTEM

SECTION 6

6-1	Systems/Circuits
550555	Audiovisual Engine Protection System
539396	Reverse Alarm Circuit
555269	Neutral Start Circuit
6-2	Components
560367	Cowl Wiring
560363	Chassis Wiring (Ref)
224207	Alternator
563052	Instrument Panel
560246	Instrument Panel Wiring
560191	Cowl Terminal Board
560085	Junction Box
-----	Battery Box - See Section 8
800004	Lighting Components
800008	Cab Warning Light

CAB & COWL

SECTION 7

7-1	Basic Structure
565450	Cab Assembly
560555	Cowl Assembly
800006	Cowl Installation Hardware
559644	Door Assembly, LH
559643	Door Assembly, RH
559647	Door Latch, LH
559646	Door Latch, RH
554939	Cab & Cowl Insulation
7-2	Instruments & Controls
564625	Engine & Transmission Controls
800005	Steering Wheel Components
211144	Steering Column
7-3	Miscellaneous
562407	Heater/Air Conditioner Installation
218869	Heater/Air Conditioner Assembly
550803	Air Conditioner Condenser Installation
214971	Cab Pressurizer
800007	Defroster
565443	Windshield Wipers, Front & Rear
553905	Seat Suspension
220900	Seat Assembly

MASTER CHECK SHEET

wagner PARTS BOOK INDEX

6 of 6

PAGE _____

L-90

MODEL _____

039297

SERIAL NO. _____

DATE 10-12-89

REVISED _____

FRAME & ATTACHMENTS

SECTION 8

558676	Boom Assembly
*566723	Carriage Assembly
-----	Tailpost - See Section 3-4
800098	Pin & Bushing Composite
800097	Miscellaneous Chassis Parts
551550	Battery Box

ACCESSORIES & OPTIONS

SECTION 9

PARTS