



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 08-Apr-04
REVISED: 23-May-05

Revision Level : H

PAGE: 1 of 6
MODEL: L90S
SERIAL NO: 039319

GENERAL INFORMATION

SECTION 1

1-1	General
-----	Master Check Sheet
80-035	How to Read Your Master Check Sheet
80-007A	Procedure For Ordering Parts (WAGNER)
1-2	Operation
800137	Alphabetical Index
579497	Decal Location / Finis List

POWER UNIT

SECTION 2

2-1	Engine
580464	Power Unit
249705	Engine, Cummins QSX15-C400 Serial Number: 79028861 Control Parts List Number: CPL8469
2-3	Lubrication
580976	Dipstick & Housing Assembly
580644	Engine Oil Fill
2-4	Fuel
558024	Fuel System Plumbing
2-5	Air Intake & Exhaust
580885	Exhaust Installation
580304	Air Cleaner Installaion
224214	Air Cleaner
2-6	Cooling
246855	Radiator/Oil Cooler/After Cooler Assembly

DRIVETRAIN

SECTION 3

3-1	General
580948	Driveline Installation
3-2	Transmission and Converter
580386	Transmission Installation
244179	Transmission
239794	Converter



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 08-Apr-04
REVISED: 23-May-05

Revision Level : H

PAGE: 2 of 6
MODEL: L90S
SERIAL NO: 039319

DRIVETRAIN

SECTION 3

3-3	Drivelines
249025	Driveline Assembly
249020	Driveline Assembly
3-4	Axles
580363	Axle Installation
577696	Tailfork Installation
577281	Parking Brake Installation
570733	Disc Brake Caliper Assembly
569926	Disc Brake Caliper Assembly
249169	Wheel End and Differential Kit
240438	Differential & Carrier
211953	Planet Carrier Assembly
3-5	Wheels & Tires
561173	Rear Wheel Assembly (Steer)
540664	Front Wheel
	Rear Tires: 26.5 X 25 Bridgestone VMT Radials
	Front Tires: 37.5 X 33 Bridgestone VKT Radials

AIR & BRAKE SYSTEMS

SECTION 4

4-1	Systems
580929	Hydraulic System - Brakes
580465	Air System - Chassis
579555	Air System - Implement Controls
4-2	Modules
579694	Air Tank Module II
579693	Air Dryer Module
4-3	Supply Components
245411	Accumulator
239658	Air Dryer
232914	Expello Valve - 24V



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 08-Apr-04
REVISED: 23-May-05

Revision Level : H

PAGE: 3 of 6
MODEL: L90S
SERIAL NO: 039319

AIR & BRAKE SYSTEMS

SECTION 4

4-4	Control Components
572376	Air Valve Assembly
246199	Brake Valve
239444	Valve, Solenoid 24V
229042	Shuttle Valve
227916	Remote Control Valve
215400	5-Spool Valve
4-5	Actuator Components
244409	Parking Brake Caliper
220326	Air Cylinder
4-6	Miscellaneous
509574	Air Hose Kit

HYDRAULIC SYSTEM

SECTION 5

5-1	Systems & Circuits
580877	Hydraulic System - Chassis
579468	Hydraulic System, Carriage
577535	Hydraulic System - Boom
574701	Hydraulic System - Steering
566611	Hydraulic System - Hoist & Tilt
5-2	Pumps
248990	Pump, Brake/Pilot
245520	Hydraulic Pump
245289	Tandem Pump
5-3	Valves
580748	Manifold Assembly
579484	Valve Module
578473	Manifold Assembly
573843	HD & KO Valve, LH & RH
244795	Holddown & Kickoff Valve, LH & RH
234082	Steering Flow Amplifier
234081	Steering Control Unit
229047	Relief Valve
225151	Valve, Hoist & Tilt



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 08-Apr-04
REVISED: 23-May-05

Revision Level : H

PAGE: 4 of 6
MODEL: L90S
SERIAL NO: 039319

HYDRAULIC SYSTEM

SECTION 5

5-4	Cylinders
W10970	Steering Cylinder
W10708	Tilt Cylinder Installation
W10390	Hydraulic Cylinder, Hoist
574867	Hydraulic Cylinder
569848	Hydraulic Cylinder
566290	Hydraulic Cylinder, Tilt
558685	Hydraulic Cylinder
526164	Hydraulic Cylinder, HD & KO
5-5	Filters
228201	High Pressure Filter (100 Gpm)
228200	High Pressure Filter (40 Gpm)

ELECTRICAL SYSTEM

SECTION 6

6-1	Systems & Circuits
577753	Reverse Alarm Circuit
6-2	Components
581163	Chassis Wiring
580845	Junction Box Assembly
580594	Terminal Panel Assembly
576827	Carriage Lights
576826	Rear Cab Lights
576825	Cab Lights
576822	Light Bar Installation
574276	Linear Actuator, Rotating Platform
570031	Cab Warning Light, Amber - 24V
234183	Alternator



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 08-Apr-04
REVISED: 23-May-05

Revision Level : H

PAGE: 5 of 6
MODEL: L90S
SERIAL NO: 039319

CAB & COWL

SECTION 7

7-1	Basic Structure
580462	Cowl Assembly
579950	Cab Assembly
572039	Door Assembly, LH
572038	Door Assembly, RH
570581	Floor Mat Installation
570421	Cab & Cowl Insulation
568456	Door Latch, RH
568431	Door Latch, LH
7-2	Instruments & Controls
580598	Electric Shift Controller
580323	Instrument Panel Assembly
580322	Dash Panel Assembly
577625	Steering Column
246923	Pedal, ElectronicThrottle
7-3	Miscellaneous
580237	Air Conditioner/Heater Installation
579756	Wiper Assembly, Rear
579755	Wiper Assembly, Front
573463	Defroster Fan Installation
570875	Training Seat Installation
238382	Air Conditioner/Heater
236982	Seat Assembly
231800	Seat Suspension

FRAME & ATTACHMENTS

SECTION 8

8-1	Frame & Attachments
580460	Chassis Assembly
579444	Carriage Assembly
577526	Boom Assembly
564345	Auxiliary Step
8-2	Miscellaneous
580721	Battery Box Installation



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 08-Apr-04
REVISED: 23-May-05

Revision Level : H

PAGE: 6 of 6
MODEL: L90S
SERIAL NO: 039319

ACCESSORIES & OPTIONS

SECTION 9

9-1	Accessories & Options
580312	Fire Suppression System
579469	Remote Lube System, Carriage
575669	Fire Suppression System, Cab