



# MASTER CHECK SHEET PARTS MANUAL INDEX

DATE:  
REVISED: 27-Jun-06

Revision Level : D

PAGE: 1 of 6  
MODEL: L90S  
SERIAL NO: 039321

---

## GENERAL INFORMATION

SECTION 1

<b>1-1</b>	<b>General</b>
-----	Master Check Sheet
80-035	How to Read Your Master Check Sheet
80-007A	Procedure For Ordering Parts (WAGNER)
<b>1-2</b>	<b>Operation</b>
800137	Alphabetical Index
579497	Decal Location / Finis List

---

## POWER UNIT

SECTION 2

<b>2-1</b>	<b>Engine</b>
580464	Power Unit
249705	Engine, Cummins QSX15-C400 Serial Number: 79083503 Arrangement Number: CPL8469
<b>2-3</b>	<b>Lubrication</b>
580976	Dipstick & Housing Assembly
580644	Engine Oil Fill
<b>2-4</b>	<b>Fuel</b>
558024	Fuel System Plumbing
<b>2-5</b>	<b>Air Intake &amp; Exhaust</b>
582958	Air Cleaner Installation
580885	Exhaust Installation
224214	Air Cleaner
<b>2-6</b>	<b>Cooling</b>
246855	Radiator/Oil Cooler/After Cooler Assembly

---

## DRIVETRAIN

SECTION 3

<b>3-1</b>	<b>General</b>
580948	Driveline Installation



# MASTER CHECK SHEET PARTS MANUAL INDEX

DATE:  
REVISED: 27-Jun-06

Revision Level : D

PAGE: 2 of 6  
MODEL: L90S  
SERIAL NO: 039321

---

## DRIVETRAIN

## SECTION 3

<b>3-2</b>	<b>Transmission and Converter</b>
582952	Transmission Circuit
580386	Transmission Installation
578293	Shift Valve, 24V
244179	Transmission
239794	Converter
228640	Pressure Regulating Valve
<b>3-3</b>	<b>Drivelines</b>
249025	Driveline Assembly
249020	Driveline Assembly
<b>3-4</b>	<b>Axles</b>
580700	Differential & Carrier
580699	Wheel End & Differential Kit
580363	Axle Installation
577696	Tailfork Installation
577281	Parking Brake Installation
570733	Disc Brake Caliper Assembly
569926	Disc Brake Caliper Assembly
211953	Planet Carrier Assembly
<b>3-5</b>	<b>Wheels &amp; Tires</b>
547331	Wheel Assembly, Drive
511427	Wheel Assembly, Rear
	Rear Tires: 23.5 X 25 Radial, TOYO
	Front Tires: 35 / 65 R 33 Radial, Michelin XRDNA

---

## AIR & BRAKE SYSTEMS

## SECTION 4

<b>4-1</b>	<b>Systems</b>
582631	Hydraulic System - Brakes
580538	Air System - Implement Controls
580465	Air System - Chassis
<b>4-2</b>	<b>Modules</b>
579693	Air Dryer Module
<b>4-3</b>	<b>Supply Components</b>
245411	Accumulator
239658	Air Dryer
232914	Expello Valve - 24V



# MASTER CHECK SHEET PARTS MANUAL INDEX

DATE:  
REVISED: 27-Jun-06

Revision Level : D

PAGE: 3 of 6  
MODEL: L90S  
SERIAL NO: 039321

---

## AIR & BRAKE SYSTEMS

## SECTION 4

<b>4-4</b>	<b>Control Components</b>
581242	Manifold Assembly
581012	Air Valve Assembly
246199	Brake Valve
239444	Valve, Solenoid 24V
227916	Remote Control Valve
215204	Valve Assembly
215115	4-Spool Valve
<b>4-5</b>	<b>Actuator Components</b>
244797	Air Cylinder
244409	Parking Brake Caliper
219110	Air Cylinder
<b>4-6</b>	<b>Miscellaneous</b>
509574	Air Hose Kit

---

## HYDRAULIC SYSTEM

## SECTION 5

<b>5-1</b>	<b>Systems &amp; Circuits</b>
582968	Hydraulic System - Steering
582639	Hydraulic System - Chassis
582636	Hydraulic System - Boom
582633	Hydraulic System - Carriage
566611	Hydraulic System - Hoist & Tilt
<b>5-2</b>	<b>Pumps</b>
248990	Pump, Brake/Pilot
245520	Hydraulic Pump
245289	Tandem Pump
<b>5-3</b>	<b>Valves</b>
582645	Brake Manifold Assembly
582634	Valve Module
573843	HD & KO Valve, LH & RH
253213	Valve Body
245851	Valve, Hoist & Tilt
239944	HD/KO Valve, LH & RH
234082	Steering Flow Amplifier
234081	Steering Control Unit
229047	Relief Valve



# MASTER CHECK SHEET PARTS MANUAL INDEX

DATE:  
REVISED: 27-Jun-06

Revision Level : D

PAGE: 4 of 6  
MODEL: L90S  
SERIAL NO: 039321

---

## HYDRAULIC SYSTEM

SECTION 5

<b>5-4</b>	<b>Cylinders</b>
W10970	Steering Cylinder
W10708	Tilt Cylinder Installation
W10390	Hydraulic Cylinder, Hoist
582701	Hydraulic Cylinder Assembly
569848	Hydraulic Cylinder
566290	Hydraulic Cylinder, Tilt
526164	Hydraulic Cylinder, HD & KO
524403	Hydraulic Cylinder
<b>5-5</b>	<b>Filters</b>
243457	Return Filter (In-Tank)
228201	High Pressure Filter (100 Gpm)
228200	High Pressure Filter (40 Gpm)

---

## ELECTRICAL SYSTEM

SECTION 6

<b>6-1</b>	<b>Systems &amp; Circuits</b>
577753	Reverse Alarm Circuit
<b>6-2</b>	<b>Components</b>
582119	Junction Box Assembly
581933	Terminal Panel Assembly
581163	Chassis Wiring
576827	Carriage Lights
576826	Rear Cab Lights
576825	Cab Lights
576822	Light Bar Installation
574276	Linear Actuator, Rotating Platform
570031	Cab Warning Light, Amber - 24V
234183	Alternator



# MASTER CHECK SHEET PARTS MANUAL INDEX

DATE:  
REVISED: 27-Jun-06

Revision Level : D

PAGE: 5 of 6  
MODEL: L90S  
SERIAL NO: 039321

---

## CAB & COWL

SECTION 7

<b>7-1</b>	<b>Basic Structure</b>
582630	Cowl Assembly
582629	Cab Assembly
572039	Door Assembly, LH
572038	Door Assembly, RH
570581	Floor Mat Installation
570421	Cab & Cowl Insulation
568456	Door Latch, RH
568431	Door Latch, LH
<b>7-2</b>	<b>Instruments &amp; Controls</b>
582112	Instrument Panel Assembly
580598	Electric Shift Controller
577625	Steering Column
246923	Pedal, ElectronicThrottle
<b>7-3</b>	<b>Miscellaneous</b>
582638	Air Conditioner / Heater Installation
581110	Cab Pressurizer
579756	Wiper Assembly, Rear
579755	Wiper Assembly, Front
578077	Brake Buttons Kit
573463	Defroster Fan Installation
570875	Training Seat Installation
238382	Air Conditioner/Heater
236982	Seat Assembly
231800	Seat Suspension

---

## FRAME & ATTACHMENTS

SECTION 8

<b>8-1</b>	<b>Frame &amp; Attachments</b>
582628	Carriage Assembly
582627	Chassis Assembly
570709	Boom Assembly
564345	Auxiliary Step
<b>8-2</b>	<b>Miscellaneous</b>
580721	Battery Box Installation



# MASTER CHECK SHEET PARTS MANUAL INDEX

DATE:

REVISED: 27-Jun-06

Revision Level : D

PAGE:

6 of 6

MODEL:

L90S

SERIAL NO:

039321

---

## ACCESSORIES & OPTIONS

SECTION 9

9-1

582635

Accessories & Options

Remote Lube System