



MASTER CHECK SHEET SERVICE MANUAL INDEX

DATE: 21 JULY 99
REVISED: 8 NOV 99

Revision Level: B

PAGE: 1 of 3
MODEL: CD1000
SERIAL NO: 068124

GENERAL INFORMATION

SECTION 1

1-1	General
-----	Master Check Sheet
80-035	How to Read Your Master Check Sheet
80-245	Manufacturer's Warranty
1-2	Operation
80-103	Start & Stop Procedures
1-3	Service
0081	Loctite Application
0130	Capscrew Grades & Torque Values
1-4	Safety
80-508	Safety Precautions

POWER UNIT

SECTION 2

2-1	Engine
3666095	Operation & Maintenance Manual - N14
2-4	Fuel
568963	Fuel System
2-5	Air Intake & Exhaust
80-045A	Air Intake System (Service)
2-6	Cooling
80-287	Radiator & Oil Cooler Service
0124	Radiator Fill Procedures
2-7	Miscellaneous
80-196	Quick Start Operation & Troubleshooting Guide

DRIVETRAIN

SECTION 3

3-2	Transmission and Converter
SMC8000	Maintenance & Service Manual - C8000 Converter
SM84	Maintenance & Service Manual - 8000 Transmission
80-486	Engine Flywheel Indicator Set-Ups
575288	Transmission Circuit
0017	Breather Maint for Converters & Trans.
3-3	Drivelines
0054	Driveline Installation & Lubricants



MASTER CHECK SHEET SERVICE MANUAL INDEX

DATE: 21 JULY 99
REVISED: 8 NOV 99

Revision Level: B

PAGE: 2 of 3
MODEL: CD1000
SERIAL NO: 068124

DRIVETRAIN (Continued)

SECTION 3

- | | |
|------------|--|
| 3-4 | Axles |
| SM21D | Maintenance & Service Manual - 21D Series Axle |
| 1014 | No-Spin Operation and Maintenance |
| 3-5 | Wheels & Tires |
| 80-510 | Wheels & Tires |

AIR & BRAKE SYSTEM

SECTION 4

- | | |
|------------|----------------------------------|
| 4-1 | Systems |
| 80-534 | Brake System Operation & Service |

HYDRAULIC SYSTEM

SECTION 5

- | | |
|------------|---|
| 5-1 | Systems & Circuits |
| 80-421 | DanFoss Steering System Operation & Troubleshooting |
| 577275 | Hydraulic Schematic |
| 575089 | Hydraulic System - Chassis |
| 574986 | Hydraulic System - Steering |
| 0087 | Troubleshooting Hydraulic Systems |
| 5-2 | Pumps |
| 80-390 | Hydraulic Pump Service |
| 80-286 | Roller Bearing Pumps Service Instructions |
| 0079 | Hydraulic Pump Failures |
| 5-3 | Valves |
| 80-568 | Service - Husco Port Relief / Anti-Cav |
| 80-423 | Steering Control Unit Service |
| 80-271 | Service Manual for HUSCO Control Valves |
| 80-241 | Remote Control Valve Service |
| 5-4 | Cylinders |
| 80-044 | Hydraulic Cylinder Repair |
| 5-5 | Filters |
| 80-553 | Hydraulic In-Tank Return Filter - Maintenance |
| 80-244 | High Pressure Filter Service |
| 5-6 | Miscellaneous |
| 80-236 | Pressurized Hydraulic Tank Warning |



MASTER CHECK SHEET SERVICE MANUAL INDEX

DATE: 21 JULY 99

REVISED: 8 NOV 99

Revision Level: B

PAGE: 3 of 3

MODEL: CD1000

SERIAL NO: 068124

ELECTRICAL SYSTEM

SECTION 6

6-1 Systems & Circuits
575311 ANSI Electrical Schematic

6-2 Components
80-333 Audio/Visual Engine Protection Service
80-238 Alternator Troubleshooting and Repair Procedures
80-092 Battery Maintenance
575008 Chassis Wiring
0161 Alternator Servicing Precautions

CAB & COWL

SECTION 7

7-3 Miscellaneous
80-512 Service - RED DOT HVAC

FRAME & ATTACHMENTS

SECTION 8

8-1 Frame & Attachments
80-222 Center Swivel Bearing Adjustment Procedure

ACCESSORIES & OPTIONS

SECTION 9

MAINTENANCE & LUBRICATION

SECTION 10

10-1 Maintenance and Lubrication
80-497 Maintenance & Lube, CHD100/CD1000
80-257 Lubricant Selection & Specifications