



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 5 JULY 99
REVISED: 8 NOV 99

Revision Level: G

PAGE: 1 of 6
MODEL: L4115E
SERIAL NO: 109247

GENERAL INFORMATION

SECTION 1

-----	Master Check Sheet
80-035	How to Read Your Master Check Sheet
80-007A	Parts Ordering Procedure
800137	Alphabetical Index
573093	Decal Location

POWER UNIT

SECTION 2

2-1	Engine
576926	Power Unit
243281	Engine, Caterpillar 3406E Serial Number: 6BR01227 Arrangement Number: 130-8140 Perf. Spec.: 166-8301
2-3	Lubrication
576920	Oil Fill Installation
576917	Dipstick & Housing Installation
2-4	Fuel
577195	Fuel System - CAT 3406 Engine
2-5	Air Intake & Exhaust
577214	Exhaust Installation
577187	Engine Intake System
226636	Air Cleaner Assembly
572395	Air Filter Indicator - In Cab
2-6	Cooling
243341	Radiator/Oil Cooler/Aftercooler Assembly
2-7	Miscellaneous
572949	Engine Block Heater Installation

DATE: 5 JULY 99

REVISED: 8 NOV 99

Revision Level: G

PAGE: 2 of 6

MODEL: L4115E

SERIAL NO: 109247

DRIVETRAIN**SECTION 3**

3-1	General
576928	Driveline Installation
3-2	Transmission and Converter
576933	Transmission Circuit
576929	Transmission Installation
241380	Transmission
239794	Converter
232904	Shift Valve Module - 24V
219271	Transmission Filter
3-3	Drivelines
577162	Driveline Assembly
576876	Driveline Assembly
243413	Driveline Assembly
242965	Driveline Assembly
242324	Driveline Assembly
3-4	Axles
576930	Front Drive Axle
575920	Rear Axle Installation
570733	Disc Brake Caliper Assembly
569926	Disc Brake Caliper Assembly
243482	Differential & Carrier
242417	Axle Assembly
240438	Differential & Carrier
211953	Planet Carrier Assembly
201087	Parking Brake
3-5	Wheels & Tires
576747	Wheel Assembly, Bogie
229546	Wheel Assembly
-----	Front Tires, 24.00 x 35 Michelin XDT Radial
-----	Rear Tires, 29.5 x 29 Michelin XHA Radial

DATE: 5 JULY 99

REVISED: 8 NOV 99

Revision Level: G

PAGE: 3 of 6

MODEL: L4115E

SERIAL NO: 109247

AIR & BRAKE SYSTEMS**SECTION 4**

4-1	Systems
576934	Hydraulic Brake System
576927	Air System - Cab
576939	Air System - Chassis
4-2	Modules
576945	Treadle Valve Module
576697	Air Valve Module
572848	Brake Relay, LH
572847	Brake Relay, RH
572843	Air Dryer Module
572830	Air Tank Assembly
572829	Air Tank Assembly
547114	Air Governor Assembly
543583	Brake Valve Module
4-3	Supply Components
545557	Air Tank Assembly
239658	Air Dryer
232914	Expello Valve - 24V
4-4	Control Components
218928	Brake Valve
216615	Relay Valve
233035	Treadle Valve
211315	Relay Valve
207917	Check Valve - Air
201352	Holdback Valve
4-5	Actuator Components
566492	Parking Brake Actuator Installation
222331	Master Cylinder
222010	Air Brake Chamber Service
220326	Air Cylinder
220267	Brake Actuator Assembly
217201	Brake Air Chamber, Parking
211711	Air Cylinder, Declutch
4-6	Miscellaneous
509574	Air Hose Kit

HYDRAULIC SYSTEM**SECTION 5**

5-1	Systems & Circuits
576932	Hydraulic System - Hoist & Tilt
572571	Hydraulic System - Cowl to Valves
572168	Hydraulic System - Steering
576923	Hydraulic System - Carriage
576931	Hydraulic System - Chassis
576935	Hydraulic System - Seat Mounted Controls

DATE: 5 JULY 99

REVISED: 8 NOV 99

Revision Level: G

PAGE: 4 of 6

MODEL: L4115E

SERIAL NO: 109247

HYDRAULIC SYSTEM (Continued)**SECTION 5**

5-2	Pumps
243513	Pump Assembly
229005	Pump Assembly
5-3	Valves
572169	Valve Module
572071	Pressure Relief Valve
236764	Remote Control Valve
239798	Remote Control Valve
236721	HD/KO Valve, LH & RH
234291	Steering Control Unit
234082	Steering Flow Amplifier
229439	Hoist & Tilt Valve
5-4	Cylinders
W11019	Hydraulic Cylinder - Hoist
576513	Steering Cylinder Assembly
576503	Steering Cylinder Installation
558313	Hydraulic Cylinder, Auxiliary HD
574863	Hydraulic Cylinder, Kickoff
574637	Hydraulic Cylinder, Holddown
576535	Tilt Cylinder Installation
576536	Tilt Cylinder Assembly
577009	Tilt Cylinder Sub-Assembly
5-5	Filters
228200	High Pressure Filter (40 gpm)
228201	High Pressure Filter (100 gpm)
224350	Return Filter (In-Tank)
5-6	Miscellaneous
575965	Low Hydraulic Oil Warning
572881	Hydraulic Load Indicator
552658	Hydraulic Tank Heater

ELECTRICAL SYSTEM**SECTION 6**

6-1	Systems & Circuits
577225	Reverse Alarm Circuit
6-2	Components
W10915	Lighting Components
577016	Junction Box Assembly
576689	Terminal Panel Assembly
572879	Light, Warning Amber
572684	Chassis Wiring
569156	Lighting Components
234183	Alternator

**MASTER CHECK SHEET
PARTS MANUAL INDEX**

DATE: 5 JULY 99

REVISED: 8 NOV 99

Revision Level: G

PAGE: 5 of 6

MODEL: L4115E

SERIAL NO: 109247

CAB & COWL**SECTION 7**

7-1	Basic Structure
576925	Cowl Assembly
576924	Cab Assembly
572039	Door Assembly, LH
572038	Door Assembly, RH
570581	Floor Mat Installation
570421	Cab & Cowl Insulation
568456	Door Latch, RH
568431	Door Latch, LH
7-2	Instruments & Controls
577143	Pedal Assembly
577142	Dash Panel Assembly
576632	Instrument Panel Assembly
573722	Steering Column
571494	Control Handle - Electric Shift
561565	Low Air Buzzer
243342	Pedal, Electric Throttle
7-3	Miscellaneous
W10822	Windshield Wiper Installation, Rear
576663	Windshield Wiper Installation, Front
575569	Heater/Air Conditioner Installation
574675	Heater Installation - Front
573234	Stereo Cassette Installation
570875	Training Seat Installation
243290	Seat Suspension
238782	Auxiliary Heater - 24V
238382	Air Conditioner/Heater
236982	Seat Assembly



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE: 5 JULY 99
REVISED: 8 NOV 99

Revision Level: G

PAGE: 6 of 6
MODEL: L4115E
SERIAL NO: 109247

FRAME & ATTACHMENTS

SECTION 8

8-1 **Frame & Attachments**
576936 Auxiliary Holddown Installation
576532 Chassis Assembly
576527 Boom Assembly
576523 Carriage Assembly
576360 Swivel Box Installation

8-2 **Miscellaneous**
551550 Battery Box
576842 Dust Baffle Installation

ACCESSORIES & OPTIONS

SECTION 9

9-1 **Accessories & Options**
572880 Remote Lube System
572878 Fire Suppression System, Chassis
571239 Fire Detection system