



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE:
REVISED: 27-Feb-06

Revision Level : B

PAGE: 1 of 6
MODEL: L4115E
SERIAL NO: 109252

GENERAL INFORMATION

SECTION 1

1-1 ----- 80-035 80-007A	General Master Check Sheet How to Read Your Master Check Sheet Procedure For Ordering Parts (WAGNER)
1-2 * 531108	Operation Decal Locations

POWER UNIT

SECTION 2

2-1 * 582295 252702	Engine Power Unit Engine, Caterpillar C15 S/N: JRE00516 Perf. Spec.: OK-5581 Arrangement Number: 254-3835
2-3 581670 576920	Lubrication Dipstick & Housing Installation Engine Oil Fill
2-4 582624 577195	Fuel Fuel Cooler Installation Fuel System
2-5 582294 502122 581577 226636	Air Intake & Exhaust Exhaust Installation Air Filter Indicator - In Cab Engine Intake System Air Filter
2-6 582299 253072 250745 250744	Cooling Radiator Installation Oil Cooler Transmission Cooler Radiator W/CAC

DRIVETRAIN

SECTION 3

3-1 581092	General Driveline Installation
----------------------	--

* Backordered



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE:
REVISED: 27-Feb-06

Revision Level : B

PAGE: 2 of 6
MODEL: L4115E
SERIAL NO: 109252

DRIVETRAIN

SECTION 3

3-2	Transmission and Converter
* 582297	Transmission Circuit
581893	Ground Speed Sensor
579954	Transmission Installation
578293	Shift Valve, 24V
248962	Converter
247471	Transmission
228640	Pressure Regulating Valve
3-3	Drivelines
249667	Driveline Assembly
249303	Driveline Assembly
249023	Driveline Assembly
249017	Driveline Assembly
249014	Driveline Assembly
248963	Driveline Assembly
3-4	Axles
581094	Rear Axle Installation
581093	Axle w/3 Calipers
577281	Parking Brake Installation
570733	Disc Brake Caliper Assembly
569926	Disc Brake Caliper Assembly
251149	Differential & Carrier Assembly
250234	Axle, Rear Chassis
240602	Planetary Assembly
240438	Differential & Carrier
211953	Planet Carrier Assembly
3-5	Wheels & Tires
576747	Wheel Assembly, Bogie
229546	Wheel Assembly, Drive

AIR & BRAKE SYSTEMS

SECTION 4

4-1	Systems
581103	Brake System Hydraulics
577747	Air System - Chassis
577365	Air System - Cab
4-2	Modules
577407	Air Governor

* Backordered



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE:
REVISED: 27-Feb-06

Revision Level : B

PAGE: 3 of 6
MODEL: L4115E
SERIAL NO: 109252

AIR & BRAKE SYSTEMS

SECTION 4

4-3	Supply Components
577408	Air Tank Assembly
245411	Accumulator
232914	Expello Valve - 24V
4-4	Control Components
581242	Manifold Assembly
244868	Brake Valve
4-5	Actuator Components
244409	Parking Brake Caliper
4-6	Miscellaneous
509574	Air Hose Kit

HYDRAULIC SYSTEM

SECTION 5

5-1	Systems & Circuits
582300	Hydraulic System - Cooler
582296	Hydraulic System - Chassis
581683	Hydraulic System - Seat Mounted Controls
581291	Hydraulic System - Carriage
581109	Hydraulic System - Ride Control
581099	Hydraulic System - Steering
576932	Hydraulic System - Hoist & Tilt
5-2	Pumps
252407	Hydraulic Pump
251716	Hydraulic Pump
250864	Cooling System Vane Pump
250778	Vane Motor
249424	Hydraulic Pump
248538	Pump, Rear Section
245931	Hydraulic Pump

* Backordered



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE:
REVISED: 27-Feb-06

Revision Level : B

PAGE: 4 of 6
MODEL: L4115E
SERIAL NO: 109252

HYDRAULIC SYSTEM

SECTION 5

5-3

582151
581404
581058
572071
250865
250637
249361
236721
234990
234291

Valves

Valve Module
Manifold Assembly
Manifold Assembly
Pressure Relief Valve
Manifold Assy, Fan Drive
Hoist & Tilt Valve
Remote Control Valve
HD/KO Valve, LH & RH
Steering Flow Amplifier
Steering Control Unit

5-4

W11019
577009
576536
576535
576513
576503
574863
574637
558313

Cylinders

Hydraulic Cylinder - Hoist
Tilt Cylinder Sub-Assembly
Tilt Cylinder Assembly
Tilt Cylinder Installation
Cylinder Assembly
Steering Cylinder Installation
Hydraulic Cylinder
Hydraulic Cylinder
Hydraulic Cylinder, Auxiliary HD

5-5

* 253049
243457
228201
228200

Filters

High Pressure Filter
Return Filter (In-Tank)
High Pressure Filter (100 Gpm)
High Pressure Filter (40 Gpm)

5-6

581326
578843
566262
552658
250632

Miscellaneous

Manifold Assembly, Ride Control
Low Hydraulic Oil Warning
Oil Cooler Assembly
Hydraulic Tank Heater
Manifold Assembly

ELECTRICAL SYSTEM

SECTION 6

6-1

577643

Systems & Circuits

Reverse Alarm

* Backordered



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE:
REVISED: 27-Feb-06

Revision Level : B

PAGE: 5 of 6
MODEL: L4115E
SERIAL NO: 109252

ELECTRICAL SYSTEM

SECTION 6

6-2	Components
582427	Terminal Panel Assembly
581592	Junction Box
581095	Chassis Wiring
581038	Junction Box Assembly
576827	Carriage Lights
576826	Rear Cab Lights
576825	Cab Lights
576822	Light Bar Installation
572879	Light, Warning Amber

CAB & COWL

SECTION 7

7-1	Basic Structure
582292	Cowl Assembly
581076	Cab Assembly
572039	Door Assembly, LH
572038	Door Assembly, RH
570581	Floor Mat Installation
570421	Cab & Cowl Insulation
568456	Door Latch, RH
568431	Door Latch, LH
7-2	Instruments & Controls
582428	Instrument Panel Assembly
580598	Electric Shift Controller
579408	Steering Column
561565	Low Air Buzzer
251323	Joystick Handle
251318	Joystick Handle
243342	Pedal, Electronic Throttle

* Backordered



MASTER CHECK SHEET PARTS MANUAL INDEX

DATE:
REVISED: 27-Feb-06

Revision Level : B

PAGE: 6 of 6
MODEL: L4115E
SERIAL NO: 109252

CAB & COWL

SECTION 7

7-3	Miscellaneous
582206	Windshield Washer Kit
581110	Cab Pressurizer
581107	Air Conditioner/Heater Installation
579756	Wiper Assembly, Rear
579755	Wiper Assembly, Front
577572	Stereo CD Player Installation
574675	Heater Installation - Front
573463	Defroster Fan Installation
570875	Training Seat Installation
240063	A/C Condenser, Remote Mount
238782	Auxiliary Heater - 24V
238382	Air Conditioner/Heater
236982	Seat Assembly
231800	Seat Suspension

FRAME & ATTACHMENTS

SECTION 8

8-1	Frame & Attachments
582289	Chassis Assembly
582114	Carriage Assembly w/Auxiliary Arms
581042	Swivel Box Installation
576527	Boom Assembly

8-2	Miscellaneous
580721	Battery Box Installation

ACCESSORIES & OPTIONS

SECTION 9

9-1	Accessories & Options
582656	Fire Suppression System - LVS
* 581106	Fire Suppression System
578987	Fire Detection System
578187	Fire Extinguisher Installation
572880	Remote Lube System

* Backordered