

#### **Maintenance Checklists**

Periodic scheduled maintenance is intended to be performed in a complete maintenance facility by trained mechanics. Scheduled maintenance procedures can be found by referring to the appropriate section of the service manual.

Always refer to manufacture's (e.g. engine, transmission, axle) maintenance manual before performing any maintenance.

First Shift (	(10 Hours)
---------------	------------

Perfo	rm these checks after the first shift, or after 10 hours, whichever occurs first.		
1	Check torque of expander pins. See form 80-222 in Service Manual.	OK 🗖	No 🗆

## First 50 Hours

These checks should be performed after the machine has been in service for 50 hours.

1	Check fluid levels - differential, planetaries	ок 🗖	Add 🗖
2	Check hydraulic system - hoses, fittings	ок 🗖	Repair 🗖
3	Check battery - cables & connections	ок 🗖	Repair 🗖
4	Check all driveline capscrews - torque to spec. See service forms 80-1057 Torque Specification Chart & 80-627 Driveline Service.	ок 🗖	No 🗖
5	Check electrical system - lights, options, connections	ок 🗖	No 🗖
6	Check all pins, bushings and load bearing hardware	ок 🗖	No 🗖
7	Check accumulator pre-charge (see 80-1076)	ок 🗖	No 🗖
8	Check parking brake lining wear and readjust if necessary	ок 🗖	Readjust
9	Check torque of expander pins. See form 80-222 in Service Manual.	ок 🗖	No 🗖
10	Check wheel lug nuts and studs mechanically, check torque	ок 🗖	Readjust

MECHANIC	
SUPERVISOR	
DATE	
MODEL	
SERIAL No	
HOUR METER	
DATE MODEL SERIAL No	

## First 100 Hours

These checks should be performed after the machine has been in service for 100 hours.

1	Drain and fill differential	ок 🗖	No 🗖
2	Drain and fill planetaries	ок 🗖	No □
3	Inspect wheel bearing, readjust if necessary	ок 🗖	No 🗖
4	Check wheel lug nuts and studs mechanically, check torque	ок 🗖	Readjust
5	Change transmission filters	ок 🗖	No 🗖

# **Weekly Maintenance (50 Hours)**

Perform these checks weekly, or after 50 hours, whichever occurs first.

1	Repeat the Daily/Shift maintenance (see Section 5-4-1)	ок 🗖	No 🗖
2	Check for fluid leaks - oil, fuel, water, transmission	ок 🗖	Repair 🗖
3	Check battery electrolyte level	ок 🗖	Add $\square$
4	Lubricate chassis & driveline cross assemblies	ок 🗖	No 🗖
5	Record engine rpm	High	Stall
6	Check for structural damage - inspect chassis & attachments for bending, cracking & broken welds	ок 🗖	Repair 🗖

 MECHANIC
 SUPERVISOR
DATE
MODEL
 SERIAL No
HOUR METER

5-4-2-2 94-3506-01 Rev: 06/2025



## **Bi-Weekly Maintenance (100 Hours)**

Darform thac	o chacks avor	y other week	or after 100 hou	ure whichover	occure firet
renonn mes	e checks even	v olitet week.	of aller 100 flot	urs, writchever	occurs inst.

1	Repeat the 50 hour check	ок 🗖	No 🗖
2	Check wheel lug nuts and studs mechanically, check torque	ок 🗖	Repair 🗖

## **Monthly Maintenance (250 Hours)**

Perform these checks monthly, or after 250 hours, whichever occurs first.

1	Repeat the 100 hour check	ок 🗖	No 🗖
2	Obtain engine oil sample for analysis	ок 🗖	No 🗖
3	Check axle differential oil level	ок 🗖	Add 🗖
4	Check axle planetary oil levels	ок 🗖	Add 🗖
5	Check all hydraulic pressures and record	ок 🗖	No 🗖
6	Check torque of expander pins. See form 80-222 in Service Manual.	ок 🗖	No 🗖
7	Check and adjust the parking brake (if required)	ок 🗖	No 🗖
8	Clean radiator	ок 🗖	No 🗖
9	Change hydraulic tank breather assembly	ок 🗖	No 🗖
10	Check pump mounting bolts and hose connections. Re-torque if necessary.	ок 🗖	No 🗖
11	Sample fuel. Check for water. See Section 2-4 in Service Manual.	ок 🗖	No 🗖
12	Flush fuel strainer	ок 🗖	No 🗖
13	Change pressure fuel filter	ок 🗖	No 🗖
14	Change suction fuel filter	ок 🗖	No 🗖

MECHANIC
SUPERVISOR
DATE
MODEL
SERIAL No
HOUR METER

# **Quarterly Maintenance (500 Hours)**

Perform these checks quarterly, or after 500 hours, whichever occurs first.

1	Repeat the 250 hour check	OK □	No 🗖
2	Change high pressure hydraulic filters	ок 🗖	No □
3	Change hydraulic return filters	ок 🗖	No □
4	Change transmission filters	ок 🗖	No □
5	Take oil samples from transmission, axle, and hydraulic system for analysis	ок 🗖	No □
6	Check accumulator pre-charge pressure (see 80-1076)	ок 🗖	No □
7	Change brake cooling return filters	ок 🗖	No □
8	Change engine oil & filters	ок 🗖	No □
9	Check antifreeze concentration	ок 🗖	Add $\square$
10	Test radiator pressure cap	ок 🗖	No □
11	Check charge air cooler	ок 🗖	No 🗖

MECHANIC	
SUPERVISOR	
DATE	
MODEL	
SERIAL No	
HOUR METER	

5-4-2-4 94-3506-01 Rev: 06/2025



## **Semi-Annual Maintenance (1000 Hours)**

Perform these checks semi-annually, or after 1000 hours, whichever occurs first.

1	Repeat the 500 hour check	ок 🗖	No 🗖
2	Change transmission oil	ок 🗖	No 🗖
3	Check pins and bushings for wear	ок 🗖	No □
4	Steam clean machine, inspect for structural cracks	ок 🗖	No 🗖
5	Replace cab pressurizer and air recirculation elements.	ок 🗖	No 🗖
6	Drivelines - See service form 80-627, Driveline Service & Maintenance.	ок 🗖	No 🗖
7	Drain and clean fuel tank	ок 🗖	No 🗖
8	Remove and clean fuel strainer	ок 🗖	No 🗖
9	Inspect AC system components (see 80-1082 in Service Manual)	ок 🗖	No 🗖
10	Drain and fill differential	ок 🗖	No 🗖
11	Drain and fill planetaries	ок 🗖	No 🗖
12	Inspect/replace diesel exhaust fluid tank suction filter	ок 🗖	No 🗖

## **Every 1,500 Hours, or 1 Year**

Perform these checks at 1500 hours, or 1 year, whichever occurs first. Perform all previous maintenance procedures that are due for scheduled maintenance.

1	Change coolant filter	ок 🗖	No 🗖
2	Check cooling fan belt tensioner	ок 🗖	No 🗖
3	Check for air leaks, air intake and exhaust system	ок 🗖	No 🗖
4	Check engine wiring harness	ок 🗖	No 🗖
5	Clean aftertreatment fuel injector	ок 🗖	No 🗖

IANIC	MECHANIC
ISOR	SUPERVISOR
DATE	DATE
ODEL	MODEL
AL No	SERIAL No
ETER	HOUR METER

#### **Annual Maintenance (2000 Hours)**

Perform these checks annually, or after 2000 hours, whichever occurs first.

1	Repeat the 1,000 hour check	ок 🗖	No 🗖
2	Change hydraulic oil	ок 🗖	No 🗖
3	Drivelines - Inspect slip splines for wear (backlash). See service form 80-627, Driveline Service & Maintenance	ок 🗖	No 🗖
4	Have Allied representative inspect machine (annually)	ок 🗖	No 🗖
5	Check wet disc brake lining wear	ок 🗖	No □
6	Check the swivel box wear (see 80-1166-LC120-serial number)	ок 🗖	No 🗖
7	Inspect wheel bearing preload, readjust if necessary	ок 🗖	Readjust

#### **Every 3000 Hours**

Perform these checks every 3000 hours.\*

1*	Change crankcase breather element	ок 🗖	No □
----	-----------------------------------	------	------

## **Every 4500 Hours or 3 Years**

Perform these checks every 4500 hours or 3 years, whichever occurs first.

$\vdash$		Check/clean/replace aftertreatment diesel particulate filter	OK 🗖	No 🗖
	2	Change aftertreatment diesel exhaust fluid dosing unit filter	ok □	No 🗖

MECHANIC
SUPERVISOR

DATE

MODEL

SERIAL No
HOUR METER

5-4-2-6 94-3506-01 Rev: 06/2025

<sup>\*</sup> Service interval may be reduced if engine fault codes indicate excessive crankcase pressure.



#### **Every 6,000 Hours, or 2 Years**

Perform these checks at 6000 hours, or 2 years, whichever occurs first. Perform all previous maintenance procedures that are due for scheduled maintenance.

1	Check engine mounting bolts	ок 🗖	No 🗖
2	Steam clean engine	ок 🗖	No 🗖
3	Check vibration dampener, engine	ок 🗖	No 🗖
4	Adjust overhead set	ок 🗖	No 🗖
5	Check radiator hose	ок 🗖	No 🗖
6	Check cold weather starting aids (if applicable)	ок 🗖	No 🗖
7	Test engine brake assembly	ок 🗖	No 🗖
8	Inspect engine mounts	ок 🗖	No 🗖

## **Every 10,000 Hours, or 5 Years**

Perform these checks at 10,000 hours, or 5 years, whichever occurs first. Perform all previous maintenance procedures that are due for scheduled maintenance.

1	Adjust overhead set	ок 🗖	No 🗖
2	Test and adjust engine brake assembly	ок 🗖	No 🗖

#### **Every 20,000 Hours, or 8 Years**

Perform these checks at 20,000 hours, or 8 years, whichever occurs first. Perform all previous maintenance procedures that are due for scheduled maintenance.

1	Clean and flush cooling system	ок 🗖	No 🗖
---	--------------------------------	------	------

MECHANIC	
SUPERVISOR	
DATE	
MODEL	
SERIAL No	
HOUR METER	

#### **Overhaul Schedule**

To maximize efficiency and minimize downtime and costly failures, Allied Systems Company recommends the following overhaul chart to be used. When followed closely, your equipment will last longer with less unexpected downtime. Contact your local Wagner dealer for the kits necessary to overhaul your drivetrain components or allow your dealer to overhaul the components for you. They are authorized to overhaul and test your components.

It is recommended that some components be overhauled at the same time, even if they might have some time before their required rebuild, to minimize downtime. Many components may have to be removed in order to gain access to others so the parts should all be rebuilt together. This will save you from having to tear the machine down again a few thousand operation hours later. During the overhaul process, make sure all parts are thoroughly cleaned before installation. Parts that do not receive this cleaning can cause the lubricant to become contaminated, which leads to much shorter service life.

#### **A** CAUTION

The overhaul schedule below is applicable when all preventive maintenance and oil testing is performed and only when genuine Wagner OEM replacement parts and lubricants are used. Major component overhauls may need to be performed more frequently if preventive maintenance is not performed, non-OEM replacement parts are used, and/or the machine is operated frequently on slopes, uneven terrain, or in poor traction conditions.

Component	Hours
Engine	20,000
Transmission	20,000
Converter	10,000
Pumps	10,000
Axle	20,000
Brakes	20,000*
Hydraulic Cylinders - Reseal	10,000
Hoses and Fittings	20,000

<sup>\*</sup> Or sooner if indicated during 2,000 hour wear check.

MECHANIC	
SUPERVISOR	
DATE	
MODEL	
SERIAL No	
IOUR METER	

5-4-2-8 94-3506-01 Rev: 06/2025