

#### **Maintenance Checklists**

Periodic scheduled maintenance is intended to be performed in a complete maintenance facility by trained mechanics. Scheduled maintenance procedures can be found by referring to the appropriate section of the service manual.

Always refer to manufacture's (e.g. engine, transmission, axle) maintenance manual before performing any maintenance.

#### First 50 Hours

These checks should be performed after the machine has been in service for 50 hours.

| 1 | Check fluid levels - differential, planetaries   | ок 🗖 | Add $\square$                         |
|---|--|------|---------------------------------------|
| 2 | Check hydraulic system - hoses, fittings   | ок 🗖 | Repair 🗖                              |
| 3 | Check battery - cables & connections   | ок 🗖 | Repair 🗖                              |
| 4 | Check all driveline capscrews - torque to spec. See service forms 80-1057 Torque Specification Chart & 80-627 Driveline Service. | ок 🗖 | No 🗖                                  |
| 5 | Check electrical system - lights, options, connections   | ок 🗖 | No 🗖                                  |
| 6 | Check all pins, bushings and load bearing hardware   | ок 🗖 | No 🗖                                  |
| 7 | Check accumulator pre-charge (see 80-1076)   | ок 🗖 | No 🗖                                  |
| 8 | Check parking brake lining wear and readjust if necessary  | ок 🗖 | Readjust                              |
| 9 | Check wheel lug nuts and studs mechanically, check torque  | ок 🗖 | Readjust                              |
|   |  |      | · · · · · · · · · · · · · · · · · · · |

#### **First 100 Hours**

These checks should be performed after the machine has been in service for 100 hours.

| 1 | Drain and fill differential                               | ок 🗖 | No 🗖     |
|---|---|------|----------|
| 2 | Drain and fill planetaries                                | ок 🗖 | No 🗖     |
| 3 | Inspect wheel bearing preload, readjust if necessary      | ок 🗖 | No 🗖     |
| 4 | Check wheel lug nuts and studs mechanically, check torque | ок 🗖 | Readjust |
| 5 | Change transmission filters                               | ок 🗖 | No 🗖     |

| MECHANIC   |
|------------|
| SUPERVISOR |
| DATE       |
| MODEL      |
| SERIAL No  |
| HOUR METER |
|            |

80-1414 Rev: 03-2025 1

### **Weekly Maintenance (50 Hours)**

Perform these checks weekly, or after 50 hours, whichever occurs first.

| 1 | Repeat the daily check - see form Daily/Shift Maintenance in section 5                           | ок 🗖 | No 🗖     |
|---|--|------|----------|
| 2 | Check for fluid leaks - oil, fuel, water, transmission   | ок 🗖 | Repair 🗖 |
| 3 | Check battery electrolyte level  | ок 🗖 | Add 🗖    |
| 4 | Lubricate chassis & driveline cross assemblies   | ок 🗖 | No 🗖     |
| 5 | Record engine rpm  | High | Stall    |
| 6 | Check for structural damage - inspect chassis & attachments for bending, cracking & broken welds | ок 🗖 | Repair 🗖 |

## **Bi-Weekly Maintenance (100 Hours)**

Perform these checks every other week, or after 100 hours, whichever occurs first.

| 1 | Repeat the 50 hour check                                  | ОК □ | No 🗖     |
|---|---|------|----------|
| 2 | Check wheel lug nuts and studs mechanically, check torque | ок 🗖 | Repair 🗖 |

MECHANIC
SUPERVISOR

DATE

MODEL

SERIAL No
HOUR METER



# **Monthly Maintenance (250 Hours)**

Perform these checks monthly, or after 250 hours, whichever occurs first.

| 1  | Repeat the 100 hour check   | ок 🗖 | No □  |
|----|---|------|-------|
| 2  | Obtain engine oil sample for analysis                                   | ок 🗖 | No 🗖  |
| 3  | Check axle differential oil level                                       | ок 🗖 | Add 🗖 |
| 4  | Check axle planetary oil levels   | ок 🗖 | Add 🗖 |
| 5  | Check all hydraulic pressures and record                                | ок 🗖 | No 🗖  |
| 6  | Check fire suppression actuator (if installed)                          | ок 🗖 | No 🗖  |
| 7  | Check and adjust the parking brake (if required)                        | ок 🗖 | No 🗖  |
| 8  | Clean radiator  | ок 🗖 | No 🗖  |
| 9  | Change hydraulic tank breather assembly                                 | ок 🗖 | No 🗖  |
| 10 | Check pump mounting bolts and hose connections. Re-torque if necessary. | ок 🗖 | No 🗖  |
| 11 | Change pressure fuel filter   | ок 🗖 | No 🗖  |
| 12 | Change suction fuel filter  | ок 🗖 | No 🗖  |

| <br>MECHANIC   |
|----------------|
| <br>SUPERVISOR |
| DATE           |
| MODEL          |
| SERIAL No      |
| HOUR METER     |

# **Quarterly Maintenance (500 Hours)**

Perform these checks quarterly, or after 500 hours, whichever occurs first.

| 1  | Repeat the 250 hour check   | OK □ | No 🗖          |
|----|---|------|---------------|
| 2  | Change high pressure hydraulic filters (if applicable)                      | ок 🗖 | No □          |
| 3  | Change hydraulic return filters   | ок 🗖 | No □          |
| 4  | Change transmission filters   | ок 🗖 | No □          |
| 5  | Take oil samples from transmission, axle, and hydraulic system for analysis | ок 🗖 | No □          |
| 6  | Check accumulator pre-charge pressure (see 80-1076)                         | ок 🗖 | No □          |
| 7  | Change brake cooling return filters   | ок 🗖 | No □          |
| 8  | Change engine oil & filters   | ок 🗖 | No □          |
| 9  | Check antifreeze concentration  | ок 🗖 | Add $\square$ |
| 10 | Test radiator pressure cap  | ок 🗖 | No □          |
| 11 | Check charge air cooler   | ок 🗖 | No 🗖          |

| <br>MECHANIC   |
|----------------|
| <br>SUPERVISOR |
| DATE           |
| <br>MODEL      |
| <br>SERIAL No  |
| HOUR METER     |



## **Semi-Annual Maintenance (1000 Hours)**

Perform these checks semi-annually, or after 1000 hours, whichever occurs first.

| 1  | Repeat the 500 hour check  | ок 🗖 | No 🗖 |
|----|--|------|------|
| 2  | Change transmission oil  | ок 🗖 | No 🗖 |
| 3  | Change transmission filters  | ок 🗖 | No 🗖 |
| 4  | Check pins and bushings for wear                                       | ок 🗖 | No 🗖 |
| 5  | Steam clean machine, inspect for structural cracks                     | ок 🗖 | No 🗖 |
| 6  | Replace cab pressurizer and air recirculation elements.                | ок 🗖 | No 🗖 |
| 7  | Drivelines - See service form 80-627, Driveline Service & Maintenance. | ок 🗖 | No 🗖 |
| 8  | Change the recirculating air filter elements                           | ок 🗖 | No □ |
| 9  | Remove, clean and reinstall the air filters on the evaporators         | ок 🗖 | No □ |
| 10 | Inspect AC system components (see 80-1082 in Service Manual)           | ок 🗖 | No 🗖 |
| 11 | Drain and fill differential  | ок 🗖 | No 🗖 |
| 12 | Drain and fill planetaries   | ок 🗖 | No 🗖 |
| 13 | Inspect/replace diesel exhaust fluid tank suction filter               | ок 🗖 | No 🗖 |

## **Every 1,500 Hours, or 1 Year**

Perform these checks at 1500 hours, or 1 year, whichever occurs first. Perform all previous maintenance procedures that are due for scheduled maintenance.

| 1 | Change coolant filter                              | ок 🗖 | No 🗖 |
|---|--|------|------|
| 2 | Inspect coolant filter head                        | ок 🗖 | No 🗖 |
| 3 | Check cooling fan belt tensioner                   | ок 🗖 | No 🗖 |
| 4 | Check for air leaks, air intake and exhaust system | ок 🗖 | No 🗖 |
| 5 | Check engine wiring harness                        | ок 🗖 | No 🗖 |
| 6 | Clean aftertreatment fuel injector                 | ок 🗖 | No 🗖 |
|   |  |      |      |

| MECHANIC   |
|------------|
| SUPERVISOR |
| DATE       |
| MODEL      |
| SERIAL No  |
| HOUR METER |
|            |

80-1414 Rev: 03-2025 5

### **Annual Maintenance (2000 Hours)**

Perform these checks annually, or after 2000 hours, whichever occurs first.

| 1 | Repeat the 1,000 hour check  | ок 🗖 | No 🗖     |
|---|--|------|----------|
| 2 | Change hydraulic oil   | ок 🗖 | No □     |
| 3 | Drivelines - Inspect slip splines for wear (backlash).<br>See service form 80-627, Driveline Service & Maintenance | ок 🗖 | No 🗖     |
| 4 | Have Allied representative inspect machine (annually)  | ок 🗖 | No □     |
| 5 | Check wet disc brake lining wear   | ок 🗖 | No □     |
| 6 | Inspect wheel bearing preload, readjust if necessary   | ок 🗖 | Readjust |

### **Every 3000 Hours**

Perform these checks every 3000 hours.\*

| 1* Change crankcase breather element | OK □ | No 🗖 |
|--------------------------------------|------|------|
|--------------------------------------|------|------|

# **Every 4500 Hours or 3 Years**

Perform these checks every 4500 hours or 3 years, whichever occurs first.

| 1 | Check/clean/replace aftertreatment diesel particulate filter  | ок 🗖 | No □ |
|---|---|------|------|
| 2 | Change aftertreatment diesel exhaust fluid dosing unit filter | ок 🗖 | No 🗖 |

MECHANIC
SUPERVISOR

DATE

MODEL

SERIAL No
HOUR METER

<sup>\*</sup> Service interval may be reduced if engine fault codes indicate excessive crankcase pressure.



#### **Every 6,000 Hours, or 2 Years**

Perform these checks at 6000 hours, or 2 years, whichever occurs first. Perform all previous maintenance procedures that are due for scheduled maintenance.

| 1 | Check engine mounting bolts                      | ок 🗖 | No 🗖 |
|---|--|------|------|
| 2 | Steam clean engine                               | ок 🗖 | No 🗖 |
| 3 | Check vibration dampener, engine                 | ок 🗖 | No 🗖 |
| 4 | Adjust overhead set                              | ок 🗖 | No 🗖 |
| 5 | Check radiator hose                              | ок 🗖 | No 🗖 |
| 6 | Check cold weather starting aids (if applicable) | ок 🗖 | No 🗖 |
| 7 | Test engine brake assembly                       | ок 🗖 | No 🗖 |
| 8 | Inspect engine mounts                            | ок 🗖 | No 🗖 |

## **Every 10,000 Hours, or 5 Years**

Perform these checks at 10,000 hours, or 5 years, whichever occurs first. Perform all previous maintenance procedures that are due for scheduled maintenance.

| 1 | Adjust overhead set                   | ок 🗖 | No 🗖 |
|---|---------------------------------------|------|------|
| 2 | Test and adjust engine brake assembly | ок 🗖 | No 🗖 |

### **Every 20,000 Hours, or 8 Years**

Perform these checks at 20,000 hours, or 8 years, whichever occurs first. Perform all previous maintenance procedures that are due for scheduled maintenance.

| 1 Clea | n and flush cooling system | ок 🗖 | No 🗖 |
|--------|----------------------------|------|------|
|--------|----------------------------|------|------|

| MECHANIC _ |  |
|------------|--|
| SUPERVISOR |  |
| DATE       |  |
| MODEL      |  |
| SERIAL No  |  |
| HOUR METER |  |

80-1414 Rev: 03-2025 7

#### **Overhaul Schedule**

To maximize efficiency and minimize downtime and costly failures, Allied Systems Company recommends the following overhaul chart to be used. When followed closely, your equipment will last longer with less unexpected downtime. Contact your local Wagner dealer for the kits necessary to overhaul your drivetrain components or allow your dealer to overhaul the components for you. They are authorized to overhaul and test your components.

It is recommended that some components be overhauled at the same time, even if they might have some time before their required rebuild, to minimize downtime. Many components may have to be removed in order to gain access to others so the parts should all be rebuilt together. This will save you from having to tear the machine down again a few thousand operation hours later. During the overhaul process, make sure all parts are thoroughly cleaned before installation. Parts that do not receive this cleaning can cause the lubricant to become contaminated, which leads to much shorter service life.

#### **CAUTION**

The overhaul schedule below is applicable when all preventive maintenance and oil testing is performed and only when genuine Wagner OEM replacement parts and lubricants are used. Major component overhauls may need to be performed more frequently if preventive maintenance is not performed, non-OEM replacement parts are used, and/or the machine is operated frequently on slopes, uneven terrain, or in poor traction conditions.

| Component                    | Hours  |
|------------------------------|--------|
| Engine                       | 20,000 |
| Transmission                 | 20,000 |
| Converter                    | 10,000 |
| Pumps                        | 10,000 |
| Axle                         | 20,000 |
| Brakes                       | 40,000 |
| Hydraulic Cylinders - Reseal | 10,000 |
| Hoses and Fittings           | 20,000 |

| <br>MECHANIC |
|--------------|
| SUPERVISOR   |
| <br>DATE     |
| MODEL        |
| SERIAL No    |
| HOUR METER   |